



802.11ax-HE160 - Ant 1 (Nss = 1)


Channel 47 (6185MHz)




Channel 79 (6345MHz)



Channel 111 (6505MHz)



Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11ax-HE20 - Ant 0 (Nss = 2)


Channel 33 (6115MHz)




Channel 61 (6255MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)





Channel 105 (6475MHz)



Channel 113 (6515MHz)









802.11ax-HE40 - Ant 0 (Nss = 2)


Channel 35 (6125MHz)




Channel 59 (6245MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)




Channel 107 (6485MHz)



Channel 115 (6525MHz)









802.11ax-HE80 - Ant 0 (Nss = 2)


Channel 39 (6145MHz)



Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)




Channel 119 (6545MHz)




Channel 135 (6625MHz)






802.11ax-HE160 - Ant 0 (Nss = 2)


Channel 47 (6185MHz)




Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11ax-HE20 - Ant 1 (Nss = 2)


Channel 33 (6115MHz)




Channel 61 (6255MHz)




Channel 93 (6415MHz)



Channel 97 (6435MHz)



Channel 105 (6475MHz)



Channel 113 (6515MHz)

