



802.11ax-HE20 - Ant 1 (Nss = 1)

Channel 229 (7095MHz)




802.11ax-HE40 - Ant 1 (Nss = 1)


Channel 35 (6125MHz)




Channel 67 (6285MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)



Channel 107 (6485MHz)




Channel 115 (6525MHz)




802.11ax-HE40 - Ant 1 (Nss = 1)


Channel 123 (6565MHz)




Channel 147 (6685MHz)




Channel 179 (6845MHz)




Channel 187 (6885MHz)



Channel 195 (6925MHz)




Channel 211 (7005MHz)




802.11ax-HE40 - Ant 1 (Nss = 1)

Channel 211 (7085MHz)




802.11ax-HE80 - Ant 1 (Nss = 1)


Channel 39 (6145MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)



Channel 119 (6545MHz)





Channel 135 (6625MHz)



802.11ax-HE80 - Ant 1 (Nss = 1)



Channel 151 (6705MHz)

Channel 183 (6865MHz)



Channel 199 (6945MHz)

Channel 215 (7025MHz)




802.11ax-HE160 - Ant 1 (Nss = 1)


Channel 47 (6185MHz)



Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11ax-HE20 - Ant 0 (Nss = 2)


Channel 33 (6115MHz)




Channel 65 (6275MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)




Channel 105 (6475MHz)




Channel 113 (6515MHz)



Channel 117 (6535MHz)




Channel 153 (6715MHz)




802.11ax-HE20 - Ant 0 (Nss = 2)


Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)



Channel 213 (7015MHz)




Channel 229 (7095MHz)




802.11ax-HE40 - Ant 0 (Nss = 2)


Channel 35 (6125MHz)




Channel 67 (6285MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)




Channel 107 (6485MHz)




Channel 115 (6525MHz)



Channel 123 (6565MHz)



Channel 147 (6685MHz)




802.11ax-HE40 - Ant 0 (Nss = 2)


Channel 179 (6845MHz)




Channel 187 (6885MHz)



Channel 195 (6925MHz)



Channel 211 (7005MHz)




Channel 227 (7085MHz)



802.11ax-HE80 - Ant 0 (Nss = 2)

Channel 199 (6945MHz)

Channel 215 (7025MHz)




802.11ax-HE160 - Ant 0 (Nss = 2)


Channel 47 (6185MHz)



Channel 79 (6345MHz)



Channel 111 (6505MHz)



Channel 143 (6665MHz)



Channel 175 (6825MHz)



Channel 175 (6985MHz)

