











TABLE OF CONTENTS					
• Package Contents	01				
• Specifications	02				
• Power and Pairing	03				
• Reset and Sizing	04				
• Charging	05				
• Controls	06				
• Warranty	08				
• Safety	09				
		PACKAGE CONTAINS			
	01	 Buds	 Charging Case		
	02	 USB Type-C charging Cable x1	 Extra Ear-tips (S x 1/L x 1)		
	03	 User Manual	01		
	04			02	
	05			03	
	06			04	
	08				
	09				
		EARBUD SPECIFICATIONS			
		Earbud weight: 4g (each) Speaker driver size: 10mm Supported profiles: A2DP/AVRCP/HFP/SPP/AVDTP Bluetooth version: 5.3 Earbud charging time: Up to 60 minutes Working voltage: 5V Standby time: Up to 120 hours Playtime: Up to 8 hours at 70% volume Bluetooth range: 10m Waterproof rating: IPX5 Working temperature: 0-45°C			
		CHARGING CASE SPECIFICATIONS			
		Charging case weight: 35g Charging port: Type-C The number of earbud charges from the case: 5.2 times Case charging time: Up to 90 minutes Total playtime with charging case: Up to 50 hours			
		POWER ON			
		The earbuds will automatically turn on, when you open the charging case and take earbuds out.			
		POWER OFF			
		The earbuds will automatically turn off once placed inside the charging case.			
		PAIRING			
		• Open the charging case and take the earbuds out. • Select 'Add Device' and select MD050 from the list of devices. • Your MD050 are now paired with your device and ready to use.			
		NOTE: Your MD050 will automatically connect to the last paired device as soon as you take them out of the charging case.			
			 Power On	 Power Off	
			02	03	
		RESET			
		• Make sure your earbuds are fully charged. • Regardless of whether the earphones are connected to a device or not, press and hold the left and right earphones at the same time for 10 seconds to restore the factory settings; the red and white lights will stay on for 5 seconds and go out.			
		• Place the buds inside the charging case and repeat the pairing process.			
		CHOOSING YOUR EAR TIP SIZE			
		Earbuds are fitted with medium-sized tips. However, if you find that they don't fit perfectly, please remove them and try the small and large ear tips. Follow the images and chart to learn how to wear earbuds in the right manner.			
					
			04		
		FCC Caution:			
		This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.			
		Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.			
		Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.			
		The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.			

CHARGING		CONTROLS		CONTROLS		WARRANTY		SAFETY FOR YOU AND YOUR MD050		
Earbuds		 Play/Pause Tap either earbud twice	 Answer Call / End Call Tap either earbud twice	 Reject Call Touch and hold either earbud for 2 seconds	 Voice Assistant Tap either earbud four times	The warranty covers your Noise product, including accessories against manufacturing defects (if any) for 1 year from the date of purchase.		 Do not expose the earbuds to liquids, moisture or humidity as they have electronics and battery inside.	 Don't try to disassemble your earbuds. There are no user serviceable parts inside it.	
Place both earbuds inside the case to charge them.		 Previous Song Tap the left earbud thrice	 Tap twice	 Tap thrice	 Tap twice			 Don't use abrasive cleaning solvents to clean your new earbuds. Wipe them down with a slightly damp cloth if and when necessary.	 Try not to drop the earbuds and keep them away from sharp objects such as keys in your pockets.	
Indication (on case)		 Next Song Tap the right earbud thrice	 Tap thrice	 Volume Up Tap the right earbud once	 Tap once			 Remove and clean the earbud tips regularly to ensure that you always enjoy the best sound possible.	 Only charge your earbuds from 5V USB ports such as phone chargers and laptops or PCs	
 Solid White LED	 Charging	 Volume Down Tap the left earbud once	 Tap once	 Gaming Mode Touch and hold either earbud for 2 seconds	 Touch and hold	For further information on product replacement/refund related queries, please refer to the terms and conditions mentioned in our online return policy section on www.gonoise.com .		 Do not expose the earbuds to extremely high or low temperature as this may damage the battery or even deform the plastic parts.	 Never listen to music at high volume or you may permanently damage your hearing.	
 Flashing White LED	 Charging							 Don't throw the earbuds in a fire to dispose it. The internal battery may explode..	 Pay attention to your surroundings and never wear any earphones while riding, driving or walking in traffic.	
 Solid White LED	 Fully Charged									
User Manual	05	User Manual	06	User Manual	07	User Manual	08	User Manual	09	Please refer to this manual before using the product

Instruction