



On main board - HVIN : OCPICSDSCM



→ Stick on the bottom face of the electronic board

On Host - HMV : OCP_SCM



→ Stick on the upper face of the board housing