

TEST SETUP

OCP_I0281

TEST SETUP PHOTO(s) – EUT POSITION



TEST SETUP PHOTO(s)




TEST SETUP PHOTO(s) – 30MHz < FOR FREQ < 200MHz



TEST SETUP PHOTO(s) - 200MHz < FOR FREQ < 1GHz



TEST SETUP PHOTO(S) - FOR FREQ > 1GHz



OCP_I0308

TEST SETUP PHOTO(s) – EUT POSITION



TEST SETUP PHOTO(s)



TEST SETUP PHOTO(s) – 30MHz < FOR FREQ < 200MHz



TEST SETUP PHOTO(s) - 200MHz < FOR FREQ < 1GHz



TEST SETUP PHOTO(S) - FOR FREQ > 1GHz



OCP_I0494

TEST SETUP PHOTO(s) – EUT POSITION




TEST SETUP PHOTO(s)



TEST SETUP PHOTO(s) – 30MHz < FOR FREQ < 200MHz



TEST SETUP PHOTO(s) - 200MHz < FOR FREQ < 1GHz



TEST SETUP PHOTO(S) - FOR FREQ > 1GHz

