


TEST SETUP PHOTO(S) – EUT POSITION FOR FREQ < 1GHZ




TEST SETUP PHOTO(S) - EUT POSITION FOR FREQ > 1GHZ



TEST SETUP PHOTO(S) - FOR FREQ < 200MHZ



TEST SETUP PHOTO(S) - FOR 200MHZ < FREQ < 1GHZ



TEST SETUP PHOTO(S) - FOR FREQ > 1GHz

