



On main board - HVIN : OCPICSDSCM



➔ Stick on the bottom face of the electronic board

On Host - HMV : OCP_SCM



➔ Stick on the upper face of the board housing