

EUT External Photo




Photo 1: Module with acessories




Photo 2: Module connected to external antenna

Only used for Testing

Supporting board used for testing

Antenna Port for module




Photo 3: Module used with supporting board for testing purpose



Photo 4: Module used with supporting board for testing purpose




Photo 5: battery connected to Module via supporting board and USB cable used for the configuration of module via supporting board