


磁吸无线充电宝(P17说明书设计文件)

<p>10K Magnetic Wireless Power Bank Model: P17</p> <p>User Manual</p>	<p>Portable Power Bank</p> <p>A</p>  <p>Specifications</p> <ul style="list-style-type: none"> • 10K Magnetic Wireless Power Bank • Battery capacity: 5000mAh 7.7V 38.5Wh • Type-C Input: 5V=3A 9V=2A 12V=1.5A • Type-C Output: 5V=3A 9V=3A 12V=2.5A 15V=2A • Wireless Charger Output: 15W Max 	<p>Mobile Power Product Indication</p>  <table border="1" data-bbox="1123 751 1537 899"> <tr> <td data-bbox="1123 751 1327 899">Power bank indicator light</td><td data-bbox="1327 751 1537 899"> <ul style="list-style-type: none"> ○ ○ ○ ○ 0% (Indicator light flashes) ○ ○ ○ ○ 0%-25% ○ ○ ○ ○ 25%-50% ○ ○ ○ ○ 50%-75% ○ ○ ○ ○ 75%-100% </td></tr> </table>	Power bank indicator light	<ul style="list-style-type: none"> ○ ○ ○ ○ 0% (Indicator light flashes) ○ ○ ○ ○ 0%-25% ○ ○ ○ ○ 25%-50% ○ ○ ○ ○ 50%-75% ○ ○ ○ ○ 75%-100%
Power bank indicator light	<ul style="list-style-type: none"> ○ ○ ○ ○ 0% (Indicator light flashes) ○ ○ ○ ○ 0%-25% ○ ○ ○ ○ 25%-50% ○ ○ ○ ○ 50%-75% ○ ○ ○ ○ 75%-100% 			
<p>Compatible Devices</p> <ul style="list-style-type: none"> • For Mobile Phone iPhone 16 Series/ iPhone 15 Series/ iPhone 14 Series/ iPhone 13 Series/ iPhone 12 Series <p>Please use a magnetic case to charge your phone</p> <p>C output</p> <p>Samsung Galaxy Z Fold5/ Z Flip5/23 Ultra/ S23+/ S23/S22 Ultra/ S22+/S22/ S21 FE/ S21 Ultra/ S21/ S21+/ S20 FE/ S20/ S20/ S20 Ultra/ S10E/ S10/ S10+/ S9/ S9+/ S8/ S8+/ S7 series / S6 series/ Z Flip4/ Z Flip3/ Z Flip/ Z Fold4/ Z Fold3/ Z Fold2/ Note 20 Ultra/ Note 20/ Note 10+ (5G)/ Note10 (5G)/9/8/7/6/5</p> <p>and all devices that support C port charging</p> <p>AirPods Pro 2nd Generation/AirPods 4/AirPods 3/ AirPods Pro MagSafe/AirPods Pro/AirPods 2nd Generation</p>	<p>Please Note:</p> <ol style="list-style-type: none"> 1. Only use certified PD Charging Wall Adapter to charge the device, do not plug into computer USB port or any other non-certified USB port. 2. Place your Qi-enabled device accurately in the wireless charging area when charging. 3. A PD adapter is required when charging mobile phones can be quickly charged 4. Make sure to disconnect the device from power when cleaning. 5. It is normal and safe to hear a humming noise when very close to the charger. It means that this wireless charger is adjusting its temperature to achieve a more efficient charging speed. 6. If your device can not be fully charged, this may due to high environmental temperature, please recharge after the temperature is lowered. Our charger has temperature control to safeguard your device when charging. <p>Important Safety Instructions</p> <ul style="list-style-type: none"> • Do not store device in high-temperature environment, including heat caused by intense sunlight or other forms of heat. • Do not place device in fire or other excessively hot environments. Exposure to fire or temperature above 212°F (100C) may cause explosion. • Do not use the wireless charger in excess of its output rating. Over loading outputs above rating may result in a risk of fire or injury to persons. • Do not expose the wireless charger to rain or snow. • Do not modify, repair or disassemble the unity, if so, please contact the manufacturer. Switch off the wireless charger when not in use. The wireless charger will automatically switch off when disconnected from its wall charger. 	<p>FCC Warning:</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ol style="list-style-type: none"> 1. Reorient or relocate the receiving antenna. 2. Increase the separation between the equipment and receiver. 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. 4. Consult the dealer or an experienced radio/TV technician for help. <p>FCC RF exposure statement:</p> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p></p>		

质:128铜板
品尺寸:60*85*mm

深圳市亿锋智能技术有限公司

料名称:说明书(符合RoHS标准)

产品名称	产品工程师	设计者
多功能无线充电器	詹剑锋	姜莉