

QUICK START GUIDE

MAGPLUS

This quick start guide contains important instructions for using this MAGPLUS product. Please only use this product after fully understanding the contents of this quick start guide.

Images may differ in appearance from the actual product. Contents are subject to change without prior notice.

Product components

Please check the components before use.



BATTERY

Battery

1EA

Quick start guide

1EA

How to use the power bank

Smartphone wireless charging method

After placing the power bank on the back of the smartphone case and pressing the power button, the LEDs light up and wireless charging begins.

Ensure there are no foreign metal objects (cards, magnets etc.) between the power bank and the smartphone.



How to use the power bank

Charging the power bank

You can charge the power bank, either in wired or wireless mode using lightning cable or MagSafe charger.

It is recommended to use a MFI certified Lightning cable.

* Do not charge more than 24 hours.

* Up to 13W can be charged using the fast charging adapter.



How to use the power bank

Simultaneous charging of the power bank and the smartphone

Normal method

Simultaneous charging is possible by connecting the Lightning cable to the power bank after combining the smartphone with the power bank.

Other method

Simultaneous charging is possible by combining the smartphone while charging the power bank and pressing the power button of the power bank once.

(It is not necessary to press the power button if the smartphone is connected to the power bank within 15 seconds.)

LED indicator lights

Normal charging mode

You can check the remaining battery level using the LEDs on the front of the product.



Low battery indication (under 15%) - 1 LED blinks

Charging status

When charging, the LEDs blink as below.



Simultaneous charging mode

You can charge the power bank and the smartphone at the same time.



The LEDs only blink for the first 15 seconds of charging

Simultaneous charging

The LEDs blink sequentially from bottom to top, and then the LEDs flash according to the remaining battery level.



Precautions

1. Charge the product fully before the first use.
2. Avoid using in-car chargers to charge the product, as their voltage and current may vary.
3. Do not disassemble the product, or use the product for any purpose other than that for which it was designed.
4. Do not charge the product in an enclosed space such as a car, in places that can become hot easily, or near a heat source.
5. Store and use at temperatures between 0 and 40°C.
6. Do not charge on heat-insulating surfaces such as carpets, blankets, sofas, beds, etc.
7. Do not expose the product to shocks, moisture, fire, sensitive skin, etc.
8. Do not allow the product to come into contact with water.
9. Only charge the product using a charger of appropriate voltage.
10. Keep the product out of reach of children.
11. Do not use the product in an environment where it may be damaged by pets.
12. If the product bloats due to battery malfunction, discontinue use of the product immediately.
13. When storing the product for an extended time period, charge the battery to 50% capacity every month.
14. This product is not waterproof, and no compensation shall be given in case of water damage.
15. Ensure that no conductive foreign materials enter the charger port.
16. Keep the product away from magnetic items such as credit cards, phone cards, bank books, traffic cards, etc, as the product may cause them damage.
17. Do not place in close proximity to computer monitors, televisions, or other similar electronic products.
18. When charging wirelessly, the product's temperature may increase slightly, so the smartphone may become hot; especially when using apps or games that use a significant amount of power.
19. Do not dispose of drained batteries irresponsibly.
20. When disposing of a used battery, do not place it in an incinerator or fire. Excessive heat may cause an explosion or fire.
21. When disposing of a secondary cell or battery, separate cells with different electrochemical systems and dispose of them separately.
22. To prevent battery overheating, dispose of used batteries in a discharged state.
23. We recommend that the smartphone battery is charged wirelessly when attached to a MAGPLUS smartphone case.
24. The manufacturer accepts no responsibility for damage to the product due to user negligence.
25. The warranty period for the product is 1 year from date of purchase.
26. Requires 7.5W or above Wall Charger.