


# Music Module Operation



- Press Auto Glide button (◀▶) to start 60 minute cycle of auto glide.
  - Press again to stop auto glide.
  - Auto glide speed can be adjusted with two speed buttons **1** & **2** on the top of the music module.
  - Activate bassinet light by pressing LIGHT button (💡) on the top of the music module.
- NOTE: Light will stay on in 60 minute cycles, unless button is pressed before 60 minutes are up.
- Press MUSIC button (🎵) on top of the music module to activate MUSIC. Press button multiple times to cycle through three (8) music melodies.
  - Volume can be adjusted with UP/DOWN buttons on the top of the music module.

# Consumer Information



## WARNING

Read all instructions BEFORE assembly and USE of product. KEEP INSTRUCTIONS FOR FUTURE USE.

CAUTION - This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference. (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

MPE Reminder: To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

# **Delta Children Connect**

## /Mobile App User Guide



# Index

|                                                |    |
|------------------------------------------------|----|
| Downloading App/<br>Delta Children Connect     | 4  |
| Registering Account/<br>Delta Children Connect | 5  |
| Pairing Devices to App/<br>Delta-WIFI          | 6  |
| Pairing Devices to App/<br>Delta-BT            | 9  |
| Controlling Devices/<br>App                    | 12 |
| Linking App to/<br>Alexa Skill                 | 14 |
| Controlling Devices/<br>Amazon Echo            | 17 |
| Voice Commands/<br>Amazon Echo                 | 19 |
| Resetting Devices/<br>Delta-WIFI & Delta-BT    | 21 |



# **Downloading App**


## /Delta Children Connect




# 1. Downloading App

## Delta Children Connect

- For the best experience, download the **Delta Children Connect** app by scanning the QR code below or on your devices.



- The App can also be downloaded by searching for Delta Children Connect on the **Apple® App Store** or **Google Play®**.



**Note:** If you already use the Delta Children Connect app, make sure that you are using the latest version. To find out if an update is available, go to the app store and search for Delta Children Connect.




## 2. Registering Account Delta Children Connect

\* Click on areas marked on each screen


Open the Delta Children Connect app  
and click "Register" to start the  
registration process

1




Enter your email  
and click "Get Verification Code"

2



Enter the verification code  
you received from your email

3



Set your Delta Children Connect  
password

4







# Pairing Device to App

## /Delta-WIFI




# Pairing Device To App


## Delta-WIFI

\* Click on areas marked on each screen

Click "Add Device" or the "+" icon on the top right corner of the screen



On the left sidebar, choose "WiFi Devices" and locate your device on the list, or choose Auto Scan



Select your WiFi network and set the password (5GHz Wi-Fi is not compatible with the Delta-WIFI Module)



# Pairing Device To App

## Delta-WIFI

\* Click on areas marked on each screen

If your device is plugged in and displaying a green blinking light, you can confirm the connection


5



Click "Confirm" and "Next" to continue setup


Adding device.  
Ensure that the Wi-Fi signal is good

6



Device added successfully.  
Click on "Done" to complete pairing.

7




# How to Check Your Smartphone WIFI Connection Band

## NOTE:

To find out whether you need to connect to a different Wi-Fi network to set up your device, go to Settings > Wi-Fi (or Wireless & Networks) on your smartphone.


### I see only **one** network:

If you only see one Wi-Fi network name that belongs to you, you can proceed by setting up this device with this Wi-Fi connection. (See image below)




### I see **more than one** network:

If you see more than one Wi-Fi network name from your smartphone's wireless settings page, look for a 2.4 on the Wi-Fi network list.



A **2.4 GHz** network may have ("24G," "2.4," or "24") appended to the end of the network name.

A **5 GHz** network may have ("5G" or "5") appended to the end of the network name.



# Pairing Device to App

## /Delta-BT



# Pairing Device To App

## Delta-BT





\* Click on areas marked on each screen

Click "Add Device" or the "+" icon on the top right corner of the screen

On the left sidebar, choose "WiFi Devices" and locate your device on the list, or choose Auto Scan

Allow bluetooth to start scanning devices

If your device is plugged in and displaying a continuous green light, you can click "Search" to start the pairing process.




# Pairing Device To App


## Delta-BT

\* Click on areas marked on each screen


Bluetooth Search process  
should detect your device



Select device to Add,  
by clicking on the "+" button.



Device added successfully.  
Click on "Done" to complete  
pairing.



# Controlling Devices

## /With App

# Controlling Devices With App



Click the music icon to adjust the volume level.

Click "Music" to turn on the function.  
NOTE: Switch songs by clicking "Music" ON & OFF.  
(Icon will turn white when on.)

Click the auto glide icon to adjust the bassinet speed.

Click "Auto Glide" to turn on the function.  
(Icon will turn white when on.)


Click the edit icon to customize the name of your device & adjust settings.

Click the light icon to adjust the brightness level.

Click "Night Light" to turn on the function.  
(Icon will turn white when on.)

Click "Set Time" to adjust the duration of the Music, Night Light and Auto Glide.

Click "Set Time" to turn on the function.  
(Icon will turn white when on.)



clicking the icon opens the function settings

clicking the test turns the device ON or OFF


Make sure to click the "ON" button to power on the functions.  
NOTE: The button will turn white when powered on.



# Linking App To /Alexa Skill

# Linking App To Alexa Skill



**Download the Amazon Alexa App**  
from: (Android, ios or Amazon app market)



\* Click on areas marked on each screen

In the "Skills & Games" section, **search** for "Delta Children Connect" skill

**Enable** "Delta Children Connect" skill and provide your credentials in order to link Alexa to your "Delta Children Connect" app account



# Linking App To Alexa Skill

\* Click on areas marked on each screen

Enter the email and password  
used on the Delta Children  
Connect app and  
click Link Now

4

Please allow page  
to load

5

Click "Authorize"  
to complete the process.

6


Delta Children Connect has  
been successfully linked.  
Close this window to  
discover smart home devices  
you can control with Alexa.

7

# Controlling devices with /Amazon Echo



## Controlling Devices With Amazon Echo



1. Once the Alexa skill is connected to your Delta Children Connect account, you can start to control your devices with Alexa or Amazon Echo.

2. To start controlling your device with Amazon Echo devices, refer to the Voice commands on page 19.

**NOTE:** When controlling devices with Amazon Echo, you will still have the ability to control your devices with your smartphone.

Voice  
Commands  
**Pg. 19**

# Voice Commands

## Amazon Echo

### Note:

Below are the voice commands with default names. You can change the default names from within the Delta Connect app before discovering them with Alexa, or change their names in the Alexa settings. In these examples, the default names are stated in the quotes.

### Turning (Delta-WIFI) On & OFF

*"Alexa, turn off Delta-WIFI"*

*"Alexa, turn on Delta-WIFI"*



### Music Function

*"Alexa, turn the music on"*

*"Alexa, set the music to 25%"*

*"Alexa, turn off the Music"*





# Voice Commands

## Amazon Echo

**Note:**

Below are the voice commands with default names. You can change the default names from within the Delta Connect app before discovering them with Alexa, or change their names in the Alexa settings. In these examples, the default names are stated in the quotes.

### Night Light Function

*"Alexa, turn on the night light"*

*"Alexa, set the night light to 25%"*

*"Alexa, turn off the night light"*



### Auto Glide Function

*"Alexa, turn on the auto glide"*

*"Alexa, set the auto glide to 25%"*

*"Alexa, turn off the auto glide"*



# **Resetting Devices**

## /Delta-WIFI & Delta-BT



# Resetting Delta-WIFI Device

## When do I need to reset the Delta-WIFI device?

- When the device is plugged in but not displaying a green blinking light.
- If the green light is not behaving as described, you have to reset the device  
(Use a small pin provided with the device to push the reset button for 5 seconds.)

*If the green light is not blinking, you have to reset the device first.-use a small pin provided with the device to push the reset button for 5 seconds.*

1



### Step 2/2


If green indicator light is now rapidly flashing, click "Confirm" below. If not, please repeat step 1.



*The indicator should start rapidly flashing. If it doesn't, repeat the process until it does, and then click "Confirm"*


*Adding device.  
Ensure that the Wi-Fi signal  
is good*

2



*Adding device.  
Ensure that the Wi-Fi signal  
is good*

3



# Resetting Delta-BT Device

## When do I need to reset the Delta-BT device?

- When the device is plugged in but not displaying a green light.
- If the green light is not behaving as described, you have to reset the device (Use a small pin provided with the device to push the reset button for 5 seconds.)

If the green light is not on, you have to reset the device first. Use a small pin provided with the device to push the reset button for 5 seconds.

1



\*

The night light should start rapidly flashing. If it doesn't, repeat the process until it does, and then click "Confirm".


Select device to Add, and then click on the + button.

2




Bluetooth Search process should detect your device -click on the device to add.

3



Adding device. Ensure that the Wi-Fi signal is good

4



# DELTA♥CHILDREN

Designed in New York.

**Delta Children's Products Corp.**

For customer support please visit: [www.DeltaChildren.com](http://www.DeltaChildren.com)

or contact us at: [gcs@DeltaChildren.com](mailto:gcs@DeltaChildren.com)

114 W 26th St, New York, NY 10001

(646) 435-8726