Probbitgoo Dog Training Collar User Manual



Read the full user manual before using the product.

Important Safety Information WARNING:

Not for use with aggressive dogs. Do not use this product if your dog is aggressive, or if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and other people. If you are not sure whether this product is appropriate for your dog, please consult your veterinarian or certified trainer.

CAUTION:

Safety during on-leash training. It is important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase.

Risk of skin damage. Please read and follow the instructions in this manual. Proper fit of the collar is important. A collar worn for too long or made too tight on the pet's neck may cause skin damage, ranging from redness to pressure uclers, which is commonly known as bed sores.

- Avoid leaving the collar on the dog for more than 12 hours per day.
- When possible re-position the collar on the pet's neck every 1 to 2 hours.
- Check the fit to prevent excessive pressure; follow the instructions in this manual.
- Never connect a leash to the electronic collar; it will cause excessive pressure on the contacts.
- When using a separate collar for a leash, don't put pressure on the electronic collar.
- Wash the dog's neck area and the contacts of the collar weekly with a damp cloth.

-1-


- Examine the contact area daily for any signs of a rash or a sore.
- If a rash or sore is found, discontinue use of the collar and wait until the skin is fully healed.
- If the condition persists beyond 48 hours, see your veterinarian.

These steps will help keep your pet safe and comfortable when using the devices. Millions of pets are comfortable with wearing stainless steel contacts, while some pets may be sensitive to contact pressure. It is important to do daily checks of the contact area. Discontinue use of the collar if any sign of unusual is found, and consult your local veterinarian or contact us via support@rabbitgoo.com for assistance.

Table of Contents

Components	4
Other Items You May Need	4
How the System Works	
Definition of the Product	
Operating Guide	7
How to Turn the Remote Training Collar On/Off	7
How the Transmitter Buttons Work	
How to Fit the Receiver Collar	8
How to Find the Best Stimulation Level for Your Pet	10
How to Maximize the Distance	11
The LCD Display & LED Indicator	
Charging the Device	
How to Pair the Remote Transmitter & Receiver Collar	14
How to Test the Functions	16
General Training Guide	17
General Tips	17
Teaching Basic Obedience	17
Eliminating Unwanted Behavior	20
Frequently Asked Questions	24
Trouble Shooting	25
FCC	
Pafaranca Siza for Diffarant Dogs	27

Components



Remote Transmitter



Receiver Collar



Strap







Conductive Silicone Covers



Contact Points



USB Cable



Test Bulb



Wrist Strap



User Manual

How the System Works

The Remote Training Collar is easy to use with an advanced digital display that tells you exactly what level of stimulation you are using.


The Remote Training Collar assists you in controlling your pet without a leash. At the push of a button, your Remote Transmitter sends a signal activating your dog's Receiver Collar.

Your dog will receive a safe but annoying stimulation. Your dog will quickly learn the association between the behavior and your correction in no time, and you'll have a better-behaved pet. The Remote Training Collar has proven safe, comfortable, and effective for both small and large dog breeds at least 6 months of age and over 8 lbs.

If you use the remote trainer consistently and correctly, you will be able to teach your pet basic obedience commands and correct any misbehaviour that your pet could be showing.

Definition of the Product

Remote Transmitter



Receiver Collar



Operating Guide

Step How to Turn the Remote Training Collar On/Off

To turn the Remote Transmitter on

- 1. Press and Hold the channel button or to seconds to power on the Remote Transmitter. The backlight will turn on.
- 2. The backlight will switch off after 15 seconds if there is no operation.
- 3. LCD display will turn off after 2 minutes if there is no operation. Pressing any button on the Remote Transmitter will activate it.

To turn the Remote Transmitter off

Press and Hold the channel button of for 2 seconds to power off the Remote Transmitter.

To turn the Receiver Collar on

Press and Hold the power button 0 for 2 seconds to power on the Receiver Collar. It will vibrate, and the LED indicator will start to blink green.

To turn the Receiver Collar off

Press and Hold the power button (1) for 2 seconds to power off the Receiver Collar. It will beep, and the LED indicator will turn off.

Notes: To extend the life of the batteries, turn off the Remote Transmitter and the Receiver Collar when they are not in use.



- Press ₩ / ★ / ♠ once to send a Vibration, Shock, and Warning Tone command to the Receiver Collar.
- If you Press and Hold III / ★ / ◄), the Receiver Collar will receive a consecutive command. It will stop after 10 seconds.

Notes: Please do not Press and Hold (18) / ★ / • for too long to avoid causing any physical or psychological hurt to your pet.

To select and adjust the mode:

- ① Press the Shock button, then adjust the Shock levels by pressing \oplus & \oplus .
- ③ Press the Warning Tone button, then select the Tone types by pressing ⊕ & ⊕ .

Step How to Fit the Receiver Collar

Important: The proper fit and placement of the Receiver Collar are important for effective training. The Contact Points must have direct contact with the skin of your dog's neck. To assure a proper fit, please follow the following steps:

- 1. Make sure that the Receiver Collar is turned off.
- 2. Have your pet standing comfortably (3A).
- 3. Place the Receiver Collar on your dog's neck. Center the Contact Points underneath the hair, touching the skin.

Note: It is sometimes necessary to trim the hair around the Contact Points to make sure that contact is consistent.

CAUTION: Do not shave the pet's neck as this may increase the risk of skin irritation.

- 4. The Receiver Collar should fit snugly, yet loose enough to allow one finger to fit between the strap and your pet's neck (3C).
- 5. Allow your pet to wear the collar for several minutes then recheck the fit. Check the fit again as your pet becomes more comfortable with the Receiver Collar.



6. To attach the strap to the Receiver Collar, follow the following steps:













Step How to Find the Best Vibration/Shock/ Warning Tone Level for Your Pet

The Remote Traning Collar has 99 stimulation levels for Shock mode and 16 levels for Vibration mode. Always start at the lowest level and work your way up. This allows you to choose the stimulation level that works the best for your pet, which is called the Recognition Level. A small change of your pet's behavior, such as looking around in curiosity, scratching at the collar, or flicking the ears, indicates that you may find the Recognition Level.

Follow the steps below to find your pet's Recognition Level:

- 1. Starting at Level 1 on the Digital Display, press the Vibration/Shock Button continuously for 1 to 2 seconds. Note: When the Vibration/Shock Button is held down for 10 consecutive seconds, the Transmitter will "time-out", and you must release and press the button again before an additional stimulation can be delivered.
- 2. If your pet shows no reaction, repeat the Stimulation Level several times before moving up to the next level.
- 3. YOUR PET SHOULD NOT VOCALIZE OR PANIC WHEN RECEIVING STIMULATION. IF THIS HAPPENS, THE STIMULATION LEVEL IS TOO HIGH AND YOU NEED TO GO BACK TO THE PREVIOUS LEVEL AND REPEAT THE PROCESS.
- 4. Move up through the Stimulation Levels until your pet reliably responds to the stimulation.
- 5. If your pet continues to show no response even at highest level, check the fit of the Receiver Collar. If your pet has long or thick hair, please use the longer set of Contact Points in the package. Then go back to Step1 and repeat the process.

Notes:

For Warning Tone mode, there are 8 types of tone without loudness difference. You may try each type and find the one that can best attract your pet's attention.

If the above steps cannot yield any results, check if you need to trim your pet's hair around the contact area. If your dog still shows no response to the stimulation, please contact our Customer Service via support@rabbitgoo.com for assistance.

Step How to Maximize the Distance

Many factors, such as the terrain, weather, vegetation, and transmission from other radio devices, may affect the maximum signal range of the device.

Hold the Remote Transmitter in a horizontal position away from your body to achieve optimum range. For maximum signal strength, keep the device fully and properly charged.







Typical range



Minmum range

^{*}Avoid touching the antenna or the range may decrease substantially.

Step The LCD Display & LED Indicator

*LCD Display on Remote Transmitter

a	Indicates keypad is locked.
4	Indicates Shock Mode is on
(1)	Indicates Warning Tone Mode is on
W∏g	Indicates Vibration Mode is on
(0000)	Indicates battery level
88	Indicates stimulation levels of Shock/Vibration and types of Warning Tone

*Remote Transmitter Indicator Light Definitions

Remote Transmitter Function	Remote Transmitter Indicator Light Response
Press , deliver Warning Tone command to the Receiver Collar	Green LED on when pressing the button
Press (), deliver Vibration to the Receiver Collar based on the current level displayed on the LED screen. The vibration will stop after 10 consecutive seconds and will reset after the release of the Vibration button.	Green LED on when pressing the button
Press , deliver Shock to the Receiver Collar based on the current level displayed on the LED screen. The static shock will stop after 10 consecutive seconds and will reset after the release of the Shock button.	Red LED on when pressing the button
Charging the Remote Transmitter	Green LED blinks
Remote Transmitter is fully charged	Green LED is on constantly

*Receiver Collar Indicator Light Definitions

Receiver Collar Function	Receiver Collar Indicator Light Response
System Running	Slow blinking, 1 blink every 4 seconds
Low Battery	Fast blinking, 2 blinks every 1 second
Fully Charged/Pairing Mode/ Executing the Shock,Vibration or Warning Tone Command	Indicator light is on constantly
On Charge	Slow blinking, 1 blink every 1 second



Step Charging the Device

The Remote Trainig Collar uses the Lithium-Polymer batteries. DO Not charge the device near flammable substances. Fully charge the Remote Transmitter and Receiver Collar before use.

Charge the Remote Training Collar if:

- The indicator light on the Receiver Collar is blinking rapidly.
- There is only 1 battery level bar left on the Remote Transmitter LCD display.
- The indicator light on the Remote Transmitter or Receiver collar does not come on.

Charging Steps:

- 1. Plug the adaptor into a standard wall outlet.
- 2. Lift the rubber cover on the Receiver Collar charging port.
- 3. Connect the USB cable connectors to the charging port on the Receiver Collar and the Remote Transmitter.

Connect the USB cable port to the power charger, power bank or your PC.

Notes:

For the Remote Transmitter: After fully charged, the LED indicator will be on Green constantly. The battery status bar will stop moving.

For the Receiver Collar: After fully charged, the LED indicator will be on Green constantly.

The charging process takes about 2 to 3 hours. The LED indicators on both devices will blink Green slowly during the charging.



Warning:


Please use a 5V-output charge to charge both devices. Improper chargers may cause charging damage.

If the device is charged with an improper charger, the Receiver Collar will deliver a warning tone continuously, and the LED indicator on the Remote Transmitter will blink Red.

Step How to Pair the Remote Transmitter & Receiver Collar

If your Receiver Collar does not beep when you press the Warning Tone Button on the Remote Transmitter, or you feel the Receiver Collar is not responding to the Remote Transmitter, follow these steps to pair them:

- Press and hold the power button on the Receiver Collar for 2 seconds to turn on the Receiver Collar.
- 2. Press the power button 3 times to enter the pairing mode. You will hear a beep, and the indicator is on constantly. You will now have 10 seconds to finish the pairing.



3. Press the ♠)/★/NN on the Remote Transmitter to complete the pairing. The Receiver Collar will respond to your operations on the Remote Transmitter.

Tips: You can choose Channel 1 or Channel 2 to pair the Remote Transmitter and the Receiver Collar, as the system can pair 2 Receiver Collars at the same time (in this case, you will need to purchase an additional Receiver Collar). If you cannot pair the devices successfully, please re-try the pairing in other places to see if it is due to the signal interference. You may also contact us via support@rabbitgoo.com for assistance.

Notes: The Remote Transmitter and Receiver Collar will only work on the channel you have paired. For example, if you have paired the Remote Transmitter to the Receiver Collar on Channel 1, the Remote Transmitter can control the Receiver Collar only on Channel 1, and it will not work on Channel 2.





1 Receiver Collar paired to Channel 1



1 Receiver Collar paired to Channel 2

Step How to Test the Functions

Warning Tone Test

- Press the Button to test the Warning Tone function.

 The Receiver Collar will beep along with a solid green indicator on the Receiver Collar, indicating that the Warning Tone function works.

Vibration Test

- Press the BB Button to test the Vibration function.
- The Receiver Collar will vibrate along with a solid green indicator on the Receiver Collar, indicating that the Vibration function works.


Shock Test

- Secure the Test Bulb on the Receiver Collars' Contact Points.
- Press the \$ Button to test the Shock function.
- The Test Bulb will light up along with a solid green indicator on the Receiver Collar, indicating the static shock stimulation works. Test Bulb will become brighter at higher shock levels.



Notes:

For your dog's comfort and safety, please ensure the conductive silicone covers are worn on the contact points before putting the Receiver Collar on your dog. The conductive silicone covers can deliver the static shock.



General Training Guide

General Tips

- Eliminate one misbehavior or teach one obedience command at a time. If you move too fast with training, your pet may become confused.
- Be consistent. Correct your pet every time he/she misbehaves.
- Unless you can supervise him/her, it is recommended that you
 restrict your pet from situations in which he/she has a history of
 misbehaving. However, setting up a situation as a training session
 can dramatically improve your chances of success.
- If your pet reacts to the beeps by hiding or acting fearful, redirect his/her attention to a simple and appropriate behavior, such as the "sit" command
- Your pet should be at least 6 months old and over 8 lbs before using this training collar.
- Do not play with the training collar as it is not a toy. Please only allow adults or responsible family members to use it.
- Other pets in the hearing range may be affected by the training beeps. Please conduct your training sessions out of the hearing range of other pets.

CAUTION: Never use the Remote Trainer to correct or eliminate any forms of aggressive behavior. We recommend you contact your local veterinarian or professional trainer to determine if your pet might be aggressive. See page 1 for more information.

Teaching Basic Obedience The "Sit" Command

- 1. Put a separate, non-metallic collar on your pet's neck ABOVE the Receiver Collar, and attach a leash. Note: Be sure the extra collar does not put pressure on the Contact Points. Never attach a leash to the Receiver Collar.
- 2. Hold the leash and the Remote Transmitter in one hand. Keep your other hand free to guide your pet into a "Sit" position.
- 3. Press and hold the Stimulation Button, starting at your pet's Recognition Level.

- 4. Immediately give the "Sit" command while holding down the Stimulation Button.
- 5. Release the Stimulation Button as soon as your pet is in position, and praise him/her.
- 6. Release your pet from the "Sit" command and play.
- 7. Repeat Steps 2 through 6 to reinforce the training effect.







Note: If your pet breaks the "Sit" command, repeat steps 3 through 6. Keep your pet close to you while teaching the "Sit" command.

The "Come" Command

- 1. Put a separate, non-metallic collar on your pet's neck ABOVE the Receiver Collar, and attach a leash. Note: Be sure the extra collar does not put pressure on the Contact Points. Never attach a leash to the Receiver Collar.
- 2. Hold your leash in one hand and the Remote Transmitter in the other.
- 3. Wait for your pet to walk away from you. Using the Recognition Level for your pet, press and hold the Stimulation Button on your Remote Transmitter.
- 4. Immediately give the command "Come" while continuing to hold the Stimulation Button.
- Using the leash, gently guide your pet toward you until he/she begins to come in your direction.
- 6. Immediately release the Stimulation Button as soon as your pet steps towards you and praise.
- 7. Quickly move backward as your pet begins to come towards you. Encourage your pet during the whole process.
- 8. Praise your pet when he/she returns to you.
- 9. Repeat Steps 3 through 8 to reinforce the training effect.
- 10. Once your pet responds readily to the "Come" command several times, move away from him/her without giving a command.

When your pet turns toward you, give the command "Come" (WITHOUT STIMULATION) and praise him/her while you continue to back up. Praise your pet when he/she returns to you. 11. Use your leash to prevent your pet from running past you. If your pet manages to run past you, repeat Steps 3 through 8.



The "Stay" Command

- 1. Put a separate, non-metallic collar on your pet's neck ABOVE the Receiver Collar, and attach a leash. Note: Be sure the extra collar does not put pressure on the Contact Points. Never attach a leash to the Receiver Collar.
- 2. Keep your pet on his bed. Hold your leash in one hand and the Remote Transmitter in the other.
- 3. Staying within 3 feet, walk the perimeter of the bed. Do not say anything to your pet.
- 4. If your pet tries to leave the bed, press and hold the Stimulation Button and give the "Stay" command. Continue to hold the button until your pet is back on the bed. If necessary, use the leash to guide your pet.
- 5. Praise your pet when he/she goes back to the dog bed.
- 6. Once your pet has settled for a few seconds, release him/her and play.
- 7. Repeat Steps 2 through 5 to reinforce the training effect.







Eliminating Unwanted Behavior Jumping Up

Pets often jump up to get attention. If you do not want your pet to jump on you, then such behavior should not be encouraged. That means every time your pet jumps on someone, he/she needs to be discouraged or redirected to an alternate and acceptable behavior, for which he/she could receive praise.

Note: It is best if your pet first understands the "Sit" command.

- 1. Choose your pet's Recognition Level.
- As soon as your pet lifts the paws off the ground to jump on you, press the Stimulation Button and give the command "Sit."
- 3. Release the Stimulation Button immediately once your pet is sitting, and verbally praise him/her.
- 4. If your pet ignores the stimulation, increase the Intensity Level by 1.
- 5. Practice this exercise in several different areas and use different people for distractions.







Digging

It is important to first understand why your pet is digging. Many dogs, such as terriers, were bred to flush out prey, and digging is very innate to them. Other dogs may be digging to find a cool spot to lie down, or simply out of boredom. Your pet may no longer have the desire to dig if with the following is provided:

- · A cool, shaded area for rest with plenty of water to drink.
- An alternative activity to occupy the attention, such as playing with the favorite toy and doing exercise.
- A yard free of rodents or prey that your dog may be trying to flush out.
- 1. Choose one Intensity Level higher than your pet's Recognition Level.
- 2. Place the Receiver Collar on your pet's neck and wait for at least 10 minutes before bringing him/her to the yard. No other people or pets should be in the yard, as you do not want your pet to associate the stimulation with anything other than the digging behavior. Your pet should also be securely fenced in or contained during the training.
- 3. Hide in an area or behind a window where your dog cannot see you. Wait until your pet begins to dig.
- 4. While your pet digs, press the Stimulation Button and release it when he/she stops digging. Only press the button while your pet is in the act of digging, and do not say anything to him.
- 5. If your pet ignores the stimulation, increase the Intensity Level by 1.
- Continue to watch your pet, as he/she may choose another area to dig.
- 7. Do not leave your pet in the yard unsupervised until he/she has completely stopped digging.







Chasing

Chasing is an instinctive behavior stimulated by moving objects. Some dogs have a particularly strong desire to chase that can put them in danger and leave you helpless. Never allow your dog off the leash or out of a contained area until he/she has learned the "Come" command, regardless of the distraction. Be consistent and correct your dog every time he/she chases something.

CAUTION: It is vitally important that you and your dog remain safe during the on-leash training. Your dog should be on a strong leash that is long enough for him/her to attempt to chase an object, but short enough for him/her not to reach a road or another unsafe area. You must also be physically strong enough to restrain your dog when he/she tries to chase something.


- If your dog has not learned the "Come" command, keep a leash on so you can physically stop your dog before he/she reaches the object.
- Choose one Intensity Level higher than your dog's Recognition
 I evel
- Set up a scenario where your dog is enticed to chase an object.
 Common items could be cars, motorcycles, bicycles, etc.
 (do not use toys).
- 4. When the object passes in front of your dog, make sure to hold the leash with a firm grip. As soon as your dog begins to chase the object, press and hold the Stimulation Button until he stops.
- 5. When your dog stops chasing the object, immediately release the button, walk backwards and give the command "Come." Praise your dog as he/she comes to you.
- 6. Repeat the process until your dog stops chasing the object.



Trash Raiding

The easiest way to prevent trash raiding is to remove garbage and tempting food from your pet's environment. You can use the Training Collar to teach your pet to stay away from these items; however, you must be prepared to correct your pet every time he approaches them.

- 1. Choose one Intensity Level higher than your pet's Recognition Level.
- 2. Pick a temptation for your pet and position yourself where he/she cannot see you.
- 3. While your pet's mouth is touching the temptation, press and hold the Stimulation Button. Immediately release the button when your pet leaves the temptation.
- 4. Do not say anything, as you want your pet to associate the stimulation with the behavior, not you.
- 5. If your pet does not respond to the stimulation, increase the Intensity Level by 1 and repeat the process.
- 6. Repeat this process in several different locations with different temptations.





Frequently Asked Questions

Is the Stimulation safe for my pet?	While the Stimulation is unpleasant, it is harmless to your pet. Electronic training devices require interaction and training from the owner to achieve desired results.
How old does my pet have to be before using the Remote Training Collar?	Your pet should be able to recognize basic obedience commands such as "Sit" or "Stay". Pets should be at least 6 months old before using the Trainer.
Once my pet is trained and has been obeying my commands, will he have to continue to wear the Receiver Collar?	Probably not. You may need to reinforce training with the Receiver Collar from time to time.
Is the Receiver Collar waterproof?	Yes. The receiver collar meets the lab test waterproof standard of IPX7, meaning that it can be submerged up to 1 meter in water for 30 minutes. Note: The Remote Transmitter is not waterproof. Keep the area dry during the charging process.
How can I get the largest remote range with the Remote Training Collar?	The range of the Remote Training Collar will vary according to terrain, weather, vegetation, as well as transmission from other radio devices. See "How the System Works' for tips on maximizing your range.
How long can I continuously deliver stimulation to my pet?	The maximum amount of time you can press the Stimulation Button and deliver stimulation to your pet continuously is 10 seconds. After this, the Remote Transmitter will time-out, and the Stimulation Button must be released and pressed again.

Trouble Shooting

	ĺ
My pet does not respond when I press a button.	Make sure the Receiver Collar has been turned on. Check if the battery levels of the devices are too low. Many factors can impact the control range you have with the Remote Trainer. For a list of these factors, see "How the System Works'. Test the Receiver Collar. See "How to test the functions' for details. Increase the Stimulation Level. Refer to "How to find the best Vibration/Shock Level for your pet' for more information. Make sure the Receiver Collar's Contact Points are placed snugly against your pet's skin. Refer to "How to Fit the Receiver Collar' for more information.
The Receiver Collar cannot be turned on.	Make sure the Receiver Collar has been charged. For the initial charge, be sure to charge it for 4 hours. Subsequent charges only take 2 to 3 hours.
The Receiver Collar is not responding to the Remote Transmitter.	Check if the Receiver Collar is on. If the indicator light is blinking, fully charge the Receiver Collar. Check if the two devices are properly paired. See "How to pair the Remote Transmitter & Receiver Collar" for more information.

FCC

USA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and the receiver.
- •Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- •Consult customer care, the dealer, or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.