

JXJ-Q1A-Y1

Please read the guide carefully before using

Wireless hotspot camera quick operation guide

— Download APP

Please scan the QR code below with your mobile phone to download the latest version of P6SLite APP directly.



(Android/IOS scan code)

You can also search for the keyword P6SLite in App Store, Android Market, Google Play, and Apple Store to download.

P6SLite 

二、Create account

1. Scan the QR code to log in or register.

2. Enter phone number or email and verify code.

3. Select service area.

4. Enter password and confirm.

5. Complete registration.

三、Add equipment

1. Click Add Device, select "Add WIFI Device" to reset the device.

2. Ensure the device is switched on and placed as close as possible to the camera.

3. Long press the reset button for 30s to reset the device.

4. Scan the QR code on the device to add it.

5. Wait for the device to connect to the router.

2. Device scan APP QR code to add

1. Choose a distribution method and click Continue.

2. Scan the QR code on the device.

3. Enter WiFi network information.

4. Scan the QR code on the device to add it.

5. Wait for the device to connect to the router.

Device connecting

1. The device is connecting to the router.

2. Binding device.

3. Connecting device.

4. Device connected successfully.

5. Device added successfully.

Page 1/15

Page 2/15


Page 3/15

Page 4/15



Page 5/15

Page 6/15


Page 7/15




Page 8/15





Page 9/15




Page 10/15



Page



Page 13/14




lem
g a device, it shows that the word which set after the have a password or have lost the U-shaped reset pin) long prompt appears "Reset is successful", that's it.

e offline in the device list
whether the device is connected, whether the power supply is normal, device and restart it, and try again.

d I do if the mobile APP can't connect
whether push is turned on (it is turned on) and whether there are any connection settings)

ack video does not search
whether the SD card is damaged, check the device time, and whether the time is correct.

cannot connect to WIFI?
the distance between the device and the mobile phone, the router does not turn on, the device is 5G (the device only supports 2.4G), the router may be faulty, or the equipment is filtered.



Page 15/15