



# JUKEBOX BLACK

## Instruction Manual

Item Number: MU03033



### Contents:

- 1(One) x Jukebox 15in. x 10.2in. x 6.3in.  
(38cm x 26cm x 16cm)
- 1(One) x USB-A-Type C Charging Cable 47.2in.(120cm)
- 1(One) x Instruction Manual

### Product Specification:

Speaker Output: 5W  
Size: 15in. x 10.2in. x 6.3in.(38cm x 26cm x 16cm)  
Input: 5V -2A  
RGB Lighting: 34 pieces of RGB LED  
Includes FM Radio and Sound Reactive Mode  
Power input: 120cm Type C USB Cable  
FCC ID: 2AYB6-MU03033  
Material: ABS + PP Plastic

### How To Use:

- Power on status:** Connect the TYPE-C power cord and the power red light will light up. Press and hold the "o" power switch for 2 seconds, the speaker will sound a power on prompt tone and the blue indicator light will flash.
- Bluetooth® connectivity:** After turning on the power, the speaker automatically enters the Bluetooth® pairing state, and the blue indicator light flashes. Search for the Bluetooth® audio name on the multimedia device: "BT JUKEBOX SPEAKER" and click pair. After successful pairing, the Bluetooth® audio system will emit a successful connection prompt sound and the blue indicator light will remain on. At this point, the audio can be played on the Bluetooth® audio system.  
If the Bluetooth® speaker is not connected to the device within 10 minutes after the power is turned on, it will automatically turn off and need to be restarted again. Bluetooth® audio has a loopback function, and the device that is successfully connected will automatically connect when Bluetooth® is turned on again.
- Bluetooth® music playback:** After a successful Bluetooth® connection, the device plays music directly. Short press "m" to play/pause music, long press "m" to disconnect Bluetooth® connection, short press "-<>" to play the previous song, short press ">+" to play the next song, long press "-<>" to decrease the volume and long press ">+" to increase the volume. Press and hold the "o" button for more than 2 seconds in any mode of power to shut down.
- FM RADIO:** After turning on the speaker, short press the "o" button to enter FM radio mode. Long press the "m" button to search for and store radio stations. After searching for radio stations, the first radio station will be listened to by default. Short press the ">+" button to play the next radio station, short press the "-<>" button to play the previous radio station, and short press the "o" button to return to Bluetooth® mode.

### Front

- Power supply:** Long press "o" to turn on/off all LEDs, short press "o" to switch between two LED flashing modes, with a total of 5 modes to choose from. The power on LED light is on by default.

#### ⚠ WARNING:

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker.
- Do not drop, place heavy weight or allow heavy impact to the speaker.
- PCB of battery should not be crushed and twisted.
- Battery body should not be bended.
- Do not disassemble and Do not dispose of in fire.

#### RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

**Tips:** Please do not turn the volume knob to the maximum level to prevent hearing damage and to prolong the service life of the system.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

**-"WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

**-"NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications."

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help."

FCC ID: 2AYB6-MU03033

#### Bluetooth®

The Bluetooth® word mark and logos are owned by the Bluetooth® SIG.  
All other trademarks appearing herein are the property of their respective owners.

Depends upon third party device compatibility.

**⚠ WARNING:** This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

Distributed By: 1616 Holdings, Inc  
701 Market Street, Suite 200,  
Philadelphia, PA 19106  
Made in China



### Back