

60.00 mm

90.00 mm

Indicator light description

Indicator light description

The device adopts two-color indicator light, which flashes in different colors and frequencies to represent different states of the device:


Indicator state	corresponding states
Blue light once	Unlock successfully
Red light once	Failed to unlock/ fingerprint collection
The red and blue lights flash twice at the same time	Fingerprint collection mode/ fingerprint collection successful
The red light flashed three times	Command fails
The red light dimly flashes	charging state
Long bright blue light	charge complete

Specification parameter

Note: If the device is stuck, it can be reset by trying the reset key at the bottom of the padlock or charging the padlock

Fingerprint smart padlock

Using instructions



Thank you for the purchase of this product. For your convenience, please read this instruction carefully and keep it properly.


"ANIOT" APP download

APP download method:

(1) IOS/Android mobile phone uses WeChat or the scan function of the browser to scan the following QR code to download and install;

(2) Android phones: foreign users can search for "ANIOT" in Google Play to download and install;

(3) Apple phones: foreign users search for "ANIOT" in the App Store to download and install;



1

Account registration and login

Register

Account: 15012345678901234567
Verification Code: 123456
Phone Number: +86 15012345678901234567
Password: 1234567890
Confirm Password: 1234567890
Register

1. Enter the correct mobile phone number or email address
2. Click for verification code
3. Enter the verification code
4. Enter a custom password
5. Click to register

Login

Account: 15012345678901234567
Password: 1234567890
Forgot password
Login

1. Enter the registered account
2. Enter the set password
3. Click to login

2

Scan code to add device

Device List

1. Enter the main page and click path 1 or path 2 to enter the next step

2. Click the scan code button

Scan QR Code

1. Scan the numbered QR code in the box

2. After scanning the code, click Add

3

Bluetooth add device

Device List

1. Click the bluetooth button

2. Touch the fingerprint module indicator on the lock with your finger to blink to activate Bluetooth

Search Device

1. Click the searched Bluetooth. If the Bluetooth name is not searched, click the refresh button in the upper right corner; touch the locked fingerprint again with your finger, and the indicator light will flash to activate Bluetooth

2. Click add

5

6

APP Bluetooth unlock

Device List

1. Click the unlock button

Bluetooth Unlock

1. Touch the fingerprint on the lock with your finger and then the indicator light flashes to activate the Bluetooth APP and perform the unlock after successful Bluetooth connection with the device

2. Unlock successfully

7

8

Add fingerprint

Device List

1. Click Fingerprint Settings when Bluetooth is connected on this page

2. Click the + sign in the upper right corner to add the fingerprint

Fingerprint Setting

1. Enter a custom name and click OK

2. Press the voice broadcast and the lock with the same finger until the entry is successful

9

10

Delete fingerprint

Fingerprint Setting

1. Enter the fingerprint setting page and click the delete button to the right of the added fingerprint or click Reset fingerprint

2. Click OK to delete the fingerprint

Device List

1. Prompt: Delete the fingerprint when the APP is connected to the lock; you can click to clear all fingerprints on the fingerprint management page. After deleting the fingerprint, the lock returns to the factory mode. Any finger can be unlocked by pressing the fingerprint.

11

12

Add friend

My QR Code

1. Scan my QR code in the personal center of your friend's mobile APP

2. Click OK to send the add request

Friends

1. Open the friend APP and go to the friend page and click to view the add request

2. Click agree to add friends successfully

13

14

Remark friend name

Friends

1. Enter the friend information page and click on the note

2. Enter your friend's name and click OK

Change Remark Name

1. Enter the friend information page, click the settings button in the upper right corner

2. A prompt to delete a friend pops up, click to delete a friend

15

16

Delete friend

Friends

1. Enter the friend information page, click the settings button in the upper right corner

2. A prompt to delete a friend pops up, click to delete a friend

Unfriend

1. Click to delete a friend

17

18

Authorization management

Device List

1. Click authorization management on this page

2. Swipe right button to confirm friend authorization; swipe left button to revoke friend authorization

Authorization

1. Select all volume authorization

2. Select all batch undo

17

18

Personal center

My QR Code

1. Click the QR code icon in the upper right corner

2. Check my QR code (Scan this QR code when adding friends)

Change avatar

1. Click the icon to pop up a prompt to choose a photo or choose a personal favorite picture from the album to upload

2. Edit name: Click the remarks column under the account to pop up the input field, enter the name and click OK

19

20

Introduction to the interactive function of Bluetooth fingerprint smart lock and APP

Usage Records

1. View unlock location information

Authorization

1. Open authorization

2. Turn off authorization

3. Change Remark Name

4. Unbind

Fingerprint Setting

1. Add the fingerprint

2. Delete the fingerprint

3. Empty all your fingerprints

21

22

使用距离小于20cm的产品：使用距离（使用产品时，与人的距离）

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction