

When device freeze please connect reset key.

[illegible]

This screenshot shows the Instagram app interface. At the top, there's a navigation bar with icons for home, search, post, activity, and profile. Below the navigation bar, there's a post by 'sophia' with 10 likes and 1 comment. The post features a photo of a person and a video thumbnail. The bottom of the screen shows a grid of posts.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1. Man-made damage is not covered by warranty
2. Non-Man-made damage is covered by warranty
3. Please email for tracking more details Danielsh@mobiletcl.com