







Band Edge NVNT n20 2412MHz Ant1 Emission




Band Edge NVNT n20 2462MHz Ant1 Ref




Band Edge NVNT n20 2462MHz Ant1 Emission




Band Edge NVNT n40 2422MHz Ant1 Ref



Band Edge NVNT n40 2422MHz Ant1 Emission




Band Edge NVNT n40 2452MHz Ant1 Ref



Date: 24.AUG.2024 10:29:15

Band Edge NVNT n40 2452MHz Ant1 Emission



Date: 24.AUG.2024 10:29:18

9. ANTENNA REQUIREMENT

9.1. Standard Requirement

An intentional radiator shall be designed to ensure that no antenna other than that furnished by the responsible party shall be used with the device. The use of a permanently attached antenna or of an antenna that uses a unique coupling to the intentional radiator shall be considered sufficient to comply with the provisions of this Section. The manufacturer may design the unit so that a broken antenna can be replaced by the user, but the use of a standard antenna jack or electrical connector is prohibited.

9.2. Antenna Connected Construction



The antenna connector is unique antenna and no consideration of replacement. Please see EUT photo for details.

9.3. Results


The EUT antenna is integrated antenna. It complies with the standard requirement.

10. TEST SETUP PHOTO

10.1. Photos of Radiated emission



10.2.Photos of Conducted Emission test



11. MODEL LIST

Model List					
BHT-9000	BAC-001	BHT-001	BAC-002	BHT-002	BAC-003
BHT-003	BAC-004	BHT-004	BAC-005	BHT-005	BAC-006
BHT-006	BAC-007	BHT-007	BAC-008	BHT-008	BAC-009
BHT-009	BAC-010	BHT-010	BAC-11	BHT-11	BAC-12
BHT-12	BAC-15	BHT-15	BAC-18	BHT-18	BAC-1000
BHT-1000	BAC-2000	BHT-2000	BAC-2001	BHT-2001	BAC-2002
BHT-2002	BAC-2003	BHT-2003	BAC-2004	BHT-2004	BAC-2005
BHT-2005	BAC-2006	BHT-2006	BAC-2007	BHT-2007	BAC-2008
BHT-2008	BAC-2009	BHT-2009	BAC-3000	BHT-3000	BAC-4000
BHT-4000	BAC-5000	BHT-5000	BAC-6000	BHT-6000	BAC-6001
BHT-6001	BAC-7000	BHT-7000	BAC-8000	BHT-8000	BAC-9000
BAC-100	BHT-100	BAC-200	BHT-200	BAC-208	BHT-208
BAC-300	BHT-300	BAC-400	BHT-400	BAC-500	BHT-500
BAC-600	BHT-600	BAC-700	BHT-700	BAC-800	BHT-800
BAC-900	BHT-900	BAC-101	BHT-101	BAC-201	BHT-201
BAC-301	BHT-301	BAC-401	BHT-401	BAC-501	BHT-501
BAC-601	BHT-601	BAC-701	BHT-701	BAC-801	BHT-801
BAC-901	BHT-901				

-----END OF REPORT-----