


The EUT is placed at the center of turntable





The EUT is placed at the center of turntable