INSTRUCTION MANUAL for Rosetell Meyouth Premium Massager with remote control

** GENERAL PRODUCT INFORMATION **

- Materials: Partner Plus- ABS+Silicone / Remote Control ABS+PU Coating
- 100% safe, phthalate-free and latex-free
- Partner Plus can be controlled by the Remote Control or its own buttons.

** IMPORTANT NOTICE FOR INITIAL USE **

• Make sure the product is 100% dry before charging.



OPERATING INSTRUCTIONS

- 1-2-sec. hold to turn on the toy in receiving mode, LED flashes continuously
- Option 1: Press button on toy to go through programs, LED only flashed ones on every press.
- Option 2: press on/off button on remote to start the first program, + and to go through the programs up and down, LED only flash ones on every press the + and button, press on/off button to stop vibration and set in receiving mode, LED flashes continuously
- Remote works at any time parallel to option 1.
- 1-2 sec. hold to turn off the completely

CLEANING AND CARE INSTRUCTIONS

- Cleaning is recommended before the first use and in between each use.
- Please clean the vibrator with water. A Special cleaner, disinfectant for adult wellness products or a suitable toy cleaner suggested by your retailer is always recommended.
- Alcohol is NOT recommended because sustained use of alcohol could corrode and damage the surface of the product.
- After cleaning, use a towel or soft cloth to wipe water from the surface, let it dry naturally.
- Avoid exposure to the sun.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by

one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
 -- Increase the separation between the equipment and receiver.
 -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.