




# NOVO duffel

## User Manual



---

### Summary

- 1   Contents
- 2   Getting started
- 3   How to use your **NOVO**
- 4   Cycle definitions
- 5   Maintenance
- 6   Safety features
- 7   Traveling with your **NOVO**

# Thank you for purchasing the **NOVO** duffel.

---

This product comes with a 1-year limited warranty on parts and workmanship.

Visit our site [www.dressfresh.com](http://www.dressfresh.com) to learn more and activate your guarantee.

---


## DRESSFRESH Customer Care

If you have any questions or issues with your **DRESSFRESH NOVO** duffel, please contact our support team by email: [support@dressfresh.com](mailto:support@dressfresh.com) or by phone: **1-619-289-7042** with your **serial number** and purchase receipt ready for reference. You may also contact us directly through the DRESSFRESH website.

Our team is happy to help. Welcome to the family.

## 1    Contents

- ⌚ 1 DUFFEL
- ⌚ 1 MODULE
- ⌚ 1 GRID BASE
- ⌚ 3 FILTER CARTRIDGES
- ⌚ 1 CHARGING ADAPTER & CORD
- ⌚ 2 BUNGEE STRAPS
- ⌚ 2 CARRY HANDLES
- ⌚ 1 SHOULDER STRAP



## 2 Getting started

### INSTALLATION OF NOVO™ SYSTEM COMPONENTS

- ⌚ Place grid into bottom of bag with the vented opening fitting into the module pocket opening.
- ⌚ Firmly grasp the module with the logo side facing you.
- ⌚ Insert the module into the module pocket opening. Make sure to line up the button with the opening at the top of the pocket.
- ⌚ Slide the module back over the vented opening of the grid. You will need to lift into the button opening to slide over the grid intake opening cleanly.

### FILTER CARTRIDGE INSTALLATION

- ⌚ Unpack a single filter cartridge.
- ⌚ Insert cartridge into opening on side of module. It is designed to fit in one way only.

## CHARGE THE MODULE

- ⦿ Take out the charging cord & wall adapter provided and fast charge your module.


## DOWNLOAD THE APP


- ⦿ Download our smartphone application.



To pair the NOVO™ duffel with your smartphone, please follow these steps:

- ⦿ Press the button on the module 5 times to activate Bluetooth mode (flashing blue).
- ⦿ Launch the DRESSFRESH smartphone application to connect with your bag.
- ⦿ Hit accept and allow access if prompted by your device.
- ⦿ Enter a name to save your new user profile.





### 3 How to use your NOVO

- ⌚ Place your DRY stinky items inside the bag. Make sure to zip it closed.
- ⌚ Select one of four preset cycles:  
QUICK | LIGHT | NORMAL | HEAVY
- ⌚ You can track your cycle progress on the app or by viewing the LED button. There are three steps to the process.

WORKING | FINISHING | COMPLETE

WORKING stage will show a TEAL button and TEAL countdown timer on the smartphone application.

FINISHING stage will show a MAGENTA button and MAGENTA countdown timer on the smartphone application.

COMPLETE stage will show a GREEN button and GREEN countdown timer on the smartphone application.

Please do not open the duffel until the cycle is COMPLETE. For best results, leave your items inside until the flashing GREEN light is off.

## 4 Cycle definitions

FOR MAXIMUM RESULTS FOLLOW THESE SIMPLE RULES:

- ⌚ KEEP THE INTAKE VENTS ON THE MODULE CLEAR. DO NOT PACK TOO FULL.
- ⌚ MAKE SURE YOUR ITEMS ARE DRY. WET FIBERS DO NOT ALLOW AIR FLOW.

**QUICK** – Use this cycle when leaving the gym or your game and your items are not dry. This will inhibit bacterial growth on your items.

**LIGHT** – Use this cycle to refresh a single item.

**NORMAL** – Use this cycle to refresh multiple items.

**HEAVY** – Use this cycle for hard to freshen items.

Once you run several cycles you will get a feel for which works best for you. We all stink differently, don't we?

## 5 Maintenance

**Changing filter cartridge** – remove old cartridge and see the orientation. Place new cartridge in properly to ensure fitment.

**Cleaning the grid** – if you get dirt, mud, etc. onto the grid and need to wipe it down or wash it please remove the module first, then remove the grid. You can take apart grid to clean inside as well. The grid is detergent and water safe.

**Cleaning the module** – DO NOT GET THE MODULE WET. It contains high power electronics. You can use any surface wipe to clean the exterior of the module.

Keep in mind, these items are the most germ & odor free components in your home!

## 6 Safety features

- ⌚ NOVO™ duffel has been designed to keep you safe during use.
- ⌚ DO NOT use the device if the bag is open. Always ensure all zippers and pockets are closed prior to start.
- ⌚ Follow all instructions on the smartphone app. It will ask you if the bag has been closed and if you are ready to start. Select yes to begin your chosen cycle once the bag is closed and you are ready to start.
- ⌚ NEVER open the bag during operation. The app clearly states DO NOT OPEN during a cycle run until it is READY TO OPEN at the COMPLETE stage.
- ⌚ If you need to end a cycle early, press STOP in the app or hit the button twice in a row. The bag will skip ahead to the finishing stage to wrap up the cycle. DO NOT OPEN the bag until the cycle is complete and the app says READY TO OPEN. The module light will be flashing green.
- ⌚ The NOVO™ duffel uses airlock zippers that seal the bag during operation. It is very important that these zippers are all closed prior to starting a cycle. If the main compartment or pocket zippers are damaged, DO NOT use your NOVO™ duffel. Contact our customer service team for support.
- ⌚ The NOVO™ duffel uses a durable outer material that is tear and weatherproof. If for any reason your bag has a cut or hole in it that is leaking out air, DO NOT continue using your NOVO. Contact our customer service team for support.

## 7 Traveling with your NOVO

The NOVO™ duffel is TSA compliant and is designed to fit in the overhead compartment of most major airlines. However, since the module has a large, long lasting battery, and contains electronics, you will need to remove it from the pocket and have it scanned separately. Just like your laptop.

## **FCC Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.