

Louise&Mann Symphony

ENG




Web: Louiseandmann.com

Email: support@louisevmann.com

User Manual



CONTROL OVERVIEW



1	LED indicator light
2	Volume Up/Next track button
3	Power/Multifunction button
4	Volume Down/Previous track button
5	Micro USB charging port
6	3.5mm AUX port
7	Microphone

PAIR WITH BLUETOOTH DEVICES

- Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device. You must pair the headphones with a Bluetooth enabled device before it can be used wirelessly.
- You only need to pair your headphones to each Bluetooth enabled device once. They will automatically reconnect to each device when turned on in their vicinity. If two or more devices are available, the last device paired will be the one that reconnects.

FIRST TIME USE / PAIR TO NEW DEVICE

- On your Bluetooth device, go to “settings” — “Bluetooth” ---turn on Bluetooth
- Turn the headphones on by pressing the multifunction button until LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode – **Blue/Red – Pairing mode**.
- “Louise&Mann Symphony” will appear on the Bluetooth device list, select “Louise&Mann Symphony” to establish pairing
- When pairing is successful, the LED on your headphones will glow solid BLUE. When

you want to play audio from another Bluetooth device, disconnect the headphones from the original device and follow steps 1-4 to re-pair the headphones with a new Bluetooth enabled device.

BUTTON CONTROL

Power On/Off: Long Press and hold the power/multifunction button for approximately 4 seconds.

Play/Pause: Single Press the multifunction button once to Play/Pause.

Volume Up/Next Track: Short Press “>>” button once to increase volume, long press and hold for next track

Volume Down/Previous Track: Short Press “<<” button once to increase volume, long press and hold for previous track


Hands-free mobile use: Short Press the multifunction button once to answer an incoming call. While on a call, short press the multifunction button once to end the call.

Reject a call: Long press and hold the multifunction button to reject a call.

USING AUX CABLE

Connect the wireless headphones to a smartphone, audio device or laptop (see overview diagram for location) with the 3.5mm AUX cable (included)


The next/previous song button can only be adjusted on the device that is connected through the 3.5mm AUX cable



CHARGING THE HEADPHONES

Please charge your headphones before first time use.

- When the battery is low, please charge via the included USB cable, the charging time is approximately 2-3hours and provides up 30 hours of continuous operation.
- The LED indicator light will be red during charging and will turn off once it is fully charged. When the battery is low, the LED indicator light will flash red.



Note: Headphones will not work if charging cable is still connected.

TROUBLESHOOT

- When an error occurs with the headphones, please turn off the headphones and restart it to troubleshoot
- When the headphones power is low, the Bluetooth range may be affected. Please charge the headphones to avoid disruption during use.
- Please see our website for general trouble shooting method instructions – Louiseandmann.com

WARNING

- Do not disassemble, repair or modify the headphones.
- Avoid storage at extreme temperatures , this can shorten the battery life and may affect the headphones
- Do not place product in or near fire to avoid danger, as it uses a lithium battery.
- Keep the headphones dry and do not store the headphones in damp areas to avoid damage to the headphones.
- Avoid dropping the headphones as it may cause damage to the product
- Do not immerse in water
- Do not insert jack plug into electric sockets.

SAFETY

To prolong the headphones life span and to avoid hearing damage, please do not listen to music under high volume for long periods of me.

Unsuitable for use by children under the age of three due to small parts which may cause choking

Supervise children when using the equipment.

Do not use these headphones whilst operating machinery, driving ,riding a motorbike or bicycle or in situations where an inability to hear surrounding noise may present a danger to yourself or others.Set volume to low before turning on sound.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction