

Quick Start Guide

How to Set Up the Mouse:

Plug the USB wireless receiver into the computer, wait about 3 – 5s to switch the on/off button to on and it's good to go.

How to Change DPI Setting:

There are 4 steps of DPI, 400/800/1600/3200, indicated respectively by red/purple/blue/green LED indicator. Press the DPI switch button on the bottom to switch to a desired DPI setting.

How to Adjust Report Rate:

There are 3 steps of report rate, 125hz/500hz/1000hz. Press the two side buttons at the same time for 3 seconds to shift from one to another. Report rate setting shares the same LED indicator with DPI, indicated by red/purple/blue respectively.

How Do I Know If the Battery Is Fully Charged:

When the battery life is below 15%, the indicator above the on/off switch will flash red, signaling it needs to be recharged. It flashes green while charging and stays green once it's been fully charged.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Operating channels: 2403Mhz - 2480Mhz