

Product Manual
Manuel du produit
Bedienungsanleitung
Manuale del prodotto
Manual del producto
제품 설명서
製品マニュアル
产品说明书




 Works with
Apple Find My



Fully charge the device before first use.
Chargez complètement l'appareil avant la première utilisation.
Laden Sie das Gerät vor dem ersten Gebrauch vollständig auf.
Caricare completamente il dispositivo prima del primo utilizzo.
Cargue completamente el dispositivo antes del primer uso.
처음 사용하기 전에 기기를 완전히 충전하세요.
初めて使用する前にデバイスを完全に充電してください。
首次使用前请将设备充满电。



**WARNING/AVERTISSEMENT/WARNUNG/
ATTENZIONE/ADVERTENCIA/警告/경고**



Keep the charging port dry and clean to prevent corrosion/
short circuits.

Gardez le port de charge sec et propre pour éviter la
corrosion/les courts-circuits.

Halten Sie den Ladeanschluss trocken und sauber, um
Korrosion/Kurzschlüsse zu vermeiden.

Mantenere la porta di ricarica asciutta e pulita per evitare
corrosione/cortocircuiti.

Mantenga el puerto de carga seco y limpio para evitar
corrosión o cortocircuitos.

부식/단락을 방지하려면 충전 포트를 건조하고 깨끗하게 유지하
십시오.

腐食やショートを防ぐために、充電ポートを乾燥した清潔
な状態に保ってください。



保持充电端口干燥、清洁以防止腐蚀/短路。



**Quick Guide/Guide rapide/Guía rápida/Guida rapida
빠른 가이드/퀵 가이드/快速指南**

① Power button
Bouton d'alimentation
Einschalttaste
Pulsante di accensione
Botón de encendido
전원 버튼
電源ボタン
电源按钮

② Indicators
Voyants lumineux
Kontrollleuchten
Luci di segnalazione
Luces indicadoras
표시등
表示灯
指示灯



Put the hex key in a safe place for future use.
Rangez la clé hexagonale dans un endroit sûr pour une
utilisation ultérieure.
Bewahren Sie den Inbusschlüssel für die zukünftige
Verwendung an einem sicheren Ort auf.
Riporre la chiave esagonale in un luogo sicuro per un uso
futuro.
Guarde la llave hexagonal en un lugar seguro para usarla
en el futuro.
유각 렌치는 나중에 사용할 수 있도록 안전한 곳에 보관하세요.
六角レンチは、将来使用するために安全な場所に保管して
ください。
将六角扳手放在安全的地方以备将来使用。

To use the Apple Find My app to locate this item, the latest
version of iOS, iPadOS, or macOS is recommended.
The Find Items app on Apple Watch requires the latest
version of watchOS.

Power button

- 1 On/off: Press and hold the button for 3 seconds to
turn on the device with 6 beeps; Triple-click the button
within 2 seconds to turn off the device, a confirmation
chime will sound and the light will flash three times.
- 2 The device is on if there are 3 beeps after double-
clicking the button, otherwise it is off.

Pairing and time-out

The device is in pairing mode when turned on.
Hold near device and open the Apple Find My app
and follow onscreen instructions for pairing.

The device will enter sleeping mode after 10 minutes
without pairing. Click the power button again to pair.

Lost Mode

A message will be sent to your phone (time varies)
when the device is disconnected. If your item ever goes
missing, you can put it in Lost Mode to display a
message and contact information to anyone who
might find it.

Low battery

A low-battery message will be sent to your phone when
the device is connected.

USB-C charging

Standard charging time: about 2 hours(5V, DC/0.14A).
Built-in over-charge/discharge protection.

Charging indicator

Constant green light: charging;
Green light off: fully charged.

Factory reset

Turn on the device, double click the power button, then
press and hold the power button for 5 seconds.
You will hear beeps during the process and a
confirmation chime will sound when the reset is finished.

Warranty policy

1. Two years warranty for the products to be free of
defects in material and workmanship from the day of
purchase under normal use.
2. One-year warranty for accessories and battery.
3. Limited lifetime warranty support.
4. Contact the seller or us for warranty service.

Warranty exclusions

1. Normal wear/tear and normal battery deterioration.
2. Improper use and maintenance, unauthorized
modifications or alterations.
3. No sales receipt or proof of the purchase.

Use of the Works with Apple badge means that a product
has been designed to work specifically with the technology
identified in the badge and has been certified by the product
manufacturer to meet Apple Find My network product
specifications and requirements. Apple is not responsible for
the operation of this device or use of this product or its
compliance with safety and regulatory standards.
Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad,
iPadOS, Mac, macOS and watchOS are the trademarks of
Apple Inc., registered in the U.S. and other countries. IOS is
a trademark or registered trademark of Cisco in the U.S. and
other countries and is used under license.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad,
iPadOS, Mac, macOS and watchOS
are the trademarks of Apple Inc., registered in the U.S. and
other countries. The trademark "iPhone" is used with a
license from Aiphone K.K.

FCC Warning

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,
including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by
the party responsible for compliance could void the user's
authority to operate the equipment.

This equipment has been tested and found to comply with
the limits for a Class B digital device, pursuant to part 15 of
the FCC Rules. These limits are designed to provide
reasonable protection against harmful interference in
a residential installation. This equipment generates uses
and can radiate radio frequency energy and, if not installed
and used in accordance with the instructions, may cause
harmful interference to radio communications. However,
there is no guarantee that interference will not occur in a
particular installation. If this equipment does cause harmful
interference to radio or television reception, which can be
determined by turning the equipment off and on, the user
is encouraged to try to correct the interference by one or
more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
receiver.
- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician
for help.

The device has been evaluated to meet general RF
exposure requirement. The device can be used in portable
exposure condition without restriction.