

3.15"80.01mm

3.15"80.01mm

560.0mm

onn. | Google TV

onn. 4K Streaming Box Quick Start Guide

WHAT'S IN THE BOX

TV Box x1

Remote Control x1

Quick Start Guide x1

Batteries x2

Adhesive Tape x1

HDMI Cable x1

Power Adapter x1

ADHESIVE TAPE

Tear off the bottom release paper

Stick the adhesive tape on the area within the white marking

Tear off the top release paper to stick to a flat surface

REMOTE CONTROL

Standby on/off

Profile

Enter

Up/Down

Back

Volume up

Volume down

Quick Launch Buttons

Input

Google Assistant Dashboard

Left/Right direction buttons

Live TV EPG

Home

Channel up

Channel down

Mute

DETAILS

● Front Panel

Micro USB

● Back Panel

Led Indicator

HDMI

Reset/Re-pair remote

SETUP

1

Step 1: Connection

Connect the streaming box to the TV with the HDMI cable. Connect the power adapter. A white LED light indicates Power On and a red LED light indicates Standby.

2

Step 2: Bluetooth pairing

Insert the 2 AAA batteries into the remote. Follow on-screen instructions for Bluetooth pairing. Hold both and buttons until pairing is successful.

SETUP

2

Step 3: Networking

Select your WiFi network and key in the password

3

Step 4: Setup Complete

Follow the on screen instructions to set up Google TV™.

4

•Reset Button:

• Remote Reset: long press the button for 5 seconds to reset the remote pair.

• Box Reset: long press the button and power on the box at the same time for 5 seconds, then it will enter the reset interface to remove all user data or accounts, etc.

FRONT

3.15"80.01mm

3.15"80.01mm

560.0mm

onn.

110125667

386

We'd love to hear from you. Scan with your smart-phone camera and let us know what you think.

SAFETY INFORMATION

Presence of live parts inside the device! Do not open. Risk of electric shock!

No parts should be repaired by users.

Place the device on a flat, firm and stable surface. Do not put it on a carpet or rug.

Protect the device from high temperatures, humidity, water and dust.

Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.

Do not place any objects near your device that may damage it (e.g. liquid-filled objects or candles).

Place the device in a well-ventilated location to prevent the accumulation of internal heat.

WARNING!

SAFETY INFORMATION

CAUTION

The Replacement to Battery
Risks of explosion if the battery is replaced by an incorrect type:
– replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types);
– disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
– leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
– a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

The Environment for Device
– Appropriate Operating Temperature: 0 °C to 40 °C
– Appropriate Operating Humidity: 5% ~ 85% Non-condensing

TROUBLESHOOTING

● No display after power on?

• Confirm the HDMI cable is plugged in properly.
• Make sure your TV has not entered sleep mode. Press the power button on the remote control to wake up your TV.

● TV has images but no sound?

Make sure your TV is not in mute or low volume.

● Fail to connect to the network?

Make sure Wi-Fi is functional and your box has a strong enough signal from your router.

● Remote control failure?

• Replace the battery of the remote control with a new one, and make sure it is placed in the correct polarity.
• Make sure the remote control is within the range of the TV box.
• Long press the reset button on streaming box for 5 seconds to reset the remote pair.

● Please use the original accessories to ensure safety and a better experience.

COMPLIANCE

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

COMPLIANCE

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

COMPLIANCE

Dolby Audio

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

HDMI
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Google TV is the name of this device's software experience and a trademark of Google LLC. Google and YouTube are trademarks of Google LLC. Netflix is a trademark of Netflix, Inc. All brands contained herein are trademarks of their respective owners.

BACK

Cut line

Fold line

Copy safe area

Outside bleed