


发行文件



Bobtot

Quick Setup Guide
KW79

5.1 CHANNEL HOME THEATER SYSTEM
Wireless Front & Rear Satellite Speakers

P1

发行文件



What's in the box

Subwoofer
Wireless Front Satellite Speakers
Wireless Connection FL & FR & SL & SR Satellite Speakers
3.5mm to RCA Audio Stereo Cable
TV/ARC/Optical/AUX Cable
Optical Audio Cable
Remote Control
FM Antenna Cable
User Manual
Mounting Brackets and Screws

IMPORTANT SAFETY INSTRUCTIONS


TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE AMPLIFIER PLATE. NO USER SERVICABLE PARTS INSIDE. WE RECOMMEND TAKING THE UNIT TO A QUALIFIED SERVICE TECHNICIAN FOR ANY REPAIRS.

Read the following safety instructions before operating your home theater system.

- Do not expose speakers on an unstable surface. The speaker may fall over causing serious injury to a child or adult and serious damage to the unit.
- Do not expose these speakers near water or expose them to rain or moisture.
- The speakers should be situated away from heat sources such as radiators, heat registers, stoves, or other devices that produce heat.
- To reduce the risk of fire, do not expose the unit to direct sunlight or unplug the power before moving your speakers or connecting other components to your system.
- Clean only with a soft dry cloth. Unplug the main unit from the wall outlet before cleaning.

CAUTION: Always use a power outlet that is properly grounded.



2



BEST PLACEMENT FOR 5.1 Home Theater System

1. Most people place the subwoofer in the floor of the room, near the sound source, for ease of connection. But since bass frequencies are omnidirectional, the subwoofer can be placed anywhere. Try placing it near a wall or a corner for installation convenience.
2. The center channel speaker should be placed directly in front of the listening position. If the listening position is not centered in the room, angle the speaker to direct the sound to ear level.
3. Above all, place the speakers on the wall, directly to the left and right of the center channel speaker. Angle them towards the listening position. Preferably, the tweeters should be at ear level.
4. Mount the satellite speakers on the wall, slightly behind the listening position, about 1 to 2 feet above ear level. (Note: If you don't have a wall, don't place them to the rear of the listening position and angle them forward.)

SET UP CENTER SATellite SPEAKERS
Place speakers in the ideal position using the built-in electric cables connect the center satellite speakers to the 'CEN' of the audio Output RCA socket on the subwoofer unit.





SET UP WIRELESS SATellite SPEAKERS

Front & Rear satellite speakers(FL/FR/SL/SR) with a wireless connection that you could place in any corner(12-32 feet from the subwoofer). By default, pairing is successful. If necessary, you can pair the subwoofer and rear satellite speakers after the subwoofer and rear satellite speakers are connected to the power light will turn blue. If the pairing is not successful or disconnected midway, please follow the steps below to pair:




1. Connect subwoofer and FL/FR/SL/SR satellite unit to the power supply and turn on the power switch.
2. Long press(3s) the pairing button on the subwoofer to enter pairing mode. (The indicator light will turn blue) then immediately long press(3s) the FL/FR/SL/SR satellite pairing button to start pairing (blue light Fast flashing).
3. The indicator light on the back panel is solid blue when pairing successfully.

NOTE: Do not perform any other operations during pairing.
2. Wait pairing mode after about 1 minutes



SYSTEM CONNECTION DIAGRAM

Verify that your device can be used to find the sound from audio/video for other external sound source devices, and ensure your device have an available jack to match this appropriate port on the device.



FRONT PANEL OF SUBWOOFER

ST-BY: Press the "ST-BY" button to start the system
INPUT: Switch from BT/TV/ARC/OPT/DVD/USB/SD/MMC/AUX mode.

5.1/2.1: 5.1 surround and 2.1 mode
AUTO: In FM mode, the radio will automatically search for stations and save the radio stations, and pause the radio or stop searching for stations.

CH++: Play previous song in USB/SD mode.
CH--: Previous station in FM mode.

LED Display: showing the chosen input mode, volume level and surround mode.

Volume: Turn the knob to control the volume.


SD/MMC Card Input: Insert your SD/MMC card into the slot. The subwoofer will automatically play the music.

USB input: plug in your USB drive to play automatically. (support SD)

5

P5

P6



Certification

FCC Warning
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.


-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

11



Need Help ?

Customer Care Guide

At our company, we strive to provide exceptional customer care to every one of our customers. We believe that building strong relationships with our customers is essential to the success of our business. To help us achieve this goal, we have put together the following customer care guide.

Time

We understand that our customers' time is valuable, so we will respond to any inquiries within 24 hours.

Feedback

We know that our customers are the heart of our business so we value your feedback. We encourage you to share your thoughts and ideas with us.

Solutions

If our customers encounter any issues, we will try our best to find a quick and efficient solution that meets your needs. Here is a list of our solutions:

-Our priority is to provide the highest quality customer service. Our customers are our first priority, and we are committed to providing the highest quality service.

-If you have any questions or concerns, please don't hesitate to reach out to us. We are here to help you.

Call or Message: +1 (888) 572-1718

Email: service@bobtot.net

bobtot.net

© BOBTOT // Features and specifications are subject to change and/or improvement without notice.

说明: 尺寸: 140x215mm
材质: 128G铜版纸 四色双面印刷 6张装订本

说明: 尺寸: 140x215mm
材质: 128G铜版纸 四色双面印刷 6张装订本

说明: 尺寸: 140x215mm

材质: 128G铜版纸 四色双面印刷 6张装订本

P7

P8

P9

P10

P11

P12