

## 1:16 REMOTE CONTROL CAR MANUAL MEATL CAR,2.4Ghz WIRELESS RECEIVER



NO.512



NO.687-6

### DISCLAIMER

Thank you for buying our remote control car, and enjoy yourself! In order to use this product more conveniently and safely, please read all contents of this manual carefully before using this product, and keep this manual for future reference.

### CAUTION

- Please remove the batteries from the car and remote control when not playing.
- When using remote control vehicle, please keep away from heat source and avoid exposing the remote control vehicle to direct sunlight for a long time.
- Batteries must be replaced by an adult.
- Keep your hands, hair and loose clothing away from the tires when the remote control car is running.
- Keep batteries away from children under 6+ years old.
- Do not pick up the remote control vehicle while it is moving.

### PRODUCT PARAMETERS

Product Description: 1:16 Remote Control Car  
Product size: 24.5\*11\*6cm  
Battery parameter: 3.7v 500mah li-ion Battery  
Charging time: about 150min's  
Run time: about 20-25mins  
Spray time: about 7 minutes  
Remote control distance: about 100feets  
Transmitter Battery: 2\*1.5v AA  
SPEED: about 13-15KM/H, when turn on the spray button, the car can go up to 18-20km/h.

### BATTERY SAFETY

\*Batteries can only be charged under adult supervision and do not leave rechargeable batteries unattended.  
\*Don't cover the battery while charging. Do not expose the battery to direct sunlight.  
\*Do not allow a fully charged battery to connect to a charger; Overcharging can shorten battery life.  
\*Do not let the battery near a fire or hot area, as it may cause the battery to explode.  
\*Do not dispose of batteries in a fire, as they may explode, as well as if they are damaged.  
\*Please do not use coins. If a metal conductive object such as a clip or pen is directly connected to the positive (+) and negative (-) terminals, the battery will be short-circuited, resulting in danger.

**!**  
1. Battery installation should only be carried out under adult supervision.  
2. When installing the battery, the positive and negative poles and the positive and negative poles of the battery box must be correctly identified.  
3. Do not mix old and new batteries  
4. Do not mix batteries of different types

**!**  
1. Do not place the toy in a high temperature environment, especially open fire or electric heating device, otherwise the battery will be damaged or exploded.  
2. Do not hit or beat the toy with hard objects.  
3. Do not immerse the remote control car and remote control in water, but store it in a dry and cool place.  
4. Do not leave the remote control vehicle when charging.

### HOW TO DISPOSE OF WASTE ELECTRICAL PRODUCTS



- 1 Do not place the product as household garbage.
2. Comply with local laws and regulations, properly dispose of discarded electronic products.
3. Thank you for participating in the e-recycling program.

Note: This device is made up of electronic components and batteries. For e-waste, please carry out special treatment according to local waste disposal requirements.

### PRODUCT MAINTENANCE

1. Do not be exposed to the sun or heat for a long time.
2. Turn off the power supply of the remote control car and remote control when not in use
3. Check whether the screws are loose
4. Only use the clean, dry soft cloth to clean the remote control car.
5. To avoid irreparable damage, keep the remote control car dry and away from water.
6. Check the remote control car and accessories for damage. If damage is found, do not use the remote control car until it is repaired.
7. When not in use, remove the battery from the battery compartment.

### THE PACKING LIST




Batteries x4  
Watering cans x2  
USB x2

Car x2  
Remote controls x2  
Manual x1

### BATTERY INSTALLATION

Installation and charging of lithium battery for Remote control car:  
Install the remote control car battery: Connect the attached 3.7V 500mah battery, as shown



\*How to charge the remote car battery:


Connect one end of the USB port to the battery and plug the other end into any computer USB port or compatible adapter.

\*Remote control battery installation method: Open the cover of the battery box and insert the 2\* 1.5V AA battery according to the polarity indicated.




### USE 2 X1.5V "AA" BATTERIES

### REMOTE CONTROL BUTTON OPERATION INSTRUCTIONS



1. Power switch: press to turn on the power, and press for 1 second to turn off the power.
2. Indicator description: Turn on the power, and the indicator of the remote control blinks, when the frequency is adjusted successfully, and the indicator of the remote controller is off.



PRESS THE BUTTON THE VEHICLE TURNS ON THE SPRAY MODE



OPEN THE WATER INJECTION PORT AND INJECT CLEAN WATER



ONE KEY TO TURN ON SPRAY MODE

### HOW TO PLAY


1. Please charge the toy fully before using it when charging the USB light comes on.
2. Run the car according to the buttons on the remote control instructions.
3. Tap the spray button, the remote car will spray, and press again the spray will stop.

### Adjust to go straight

1. If the remote control car does not go straight when driving forward, turn the steering adjustment button at the bottom of the remote control. The mark indicates "fine left" fine left until the remote control car can go straight.
2. If the remote control car does not go straight when moving forward, turn the steering adjustment button at the bottom of the remote control. The sign means "fine to the right", fine to the remote control car can go straight.



### TIPS

1. Do not touch the four wheels of the remote control car when the car is moving to avoid injury or damage to the remote control car.
2. Don't play on the road or in dangerous places in case of accidents. Don't play with your remote control car in dirty water, dirt or sand.



FCC ID:2AZ4E-00515

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.



FCC Caution.

(1)§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.