




80G书纸, 双面印刷, 印单色, 风琴折, 成品尺寸:70*100MM

<p>M15 蓝牙音箱 Bluetooth Speaker ブルートゥーススピーカー</p> <p>使用指南 Operating guide</p> <p>AUX Mode Insert a 3.5mm audio cable into the aux jack on the back of the speaker, connect to any audio device such as mobile phones or computers with the other port.</p> <p>TWS Bluetooth Pairing After the two speakers are turned on, press one of the  buttons twice, and the speaker will find another pair. After the pairing was retained, a brisk tone was found. At this point, connect Bluetooth to play music together. Control one of them to adjust the volume of the two units.</p> <p>Technical Parameters</p> <table border="1"> <tr><td>Battery Type:</td><td>Lithium Polymer Batteries 18650</td></tr> <tr><td>Bluetooth Model:</td><td>V5.0</td></tr> <tr><td>Effective Range:</td><td>10 Meter/33FT</td></tr> <tr><td>Charging Time:</td><td>2hours</td></tr> <tr><td>Working Voltage:</td><td>3.7V</td></tr> <tr><td>Input voltage:</td><td>5V</td></tr> <tr><td>Waterproof:</td><td>IPX7</td></tr> <tr><td>Battery Capacity:</td><td>1800mAh</td></tr> <tr><td>Distortion:</td><td>≤0.5%</td></tr> <tr><td>Weight:</td><td>245g</td></tr> </table>	Battery Type:	Lithium Polymer Batteries 18650	Bluetooth Model:	V5.0	Effective Range:	10 Meter/33FT	Charging Time:	2hours	Working Voltage:	3.7V	Input voltage:	5V	Waterproof:	IPX7	Battery Capacity:	1800mAh	Distortion:	≤0.5%	Weight:	245g	<p>使用说明</p>  <p>① 开关/播放/暂停/接听 ⑥ 充电口 ② 短按音量减/长按上一曲 ⑦ TF卡 ③ 短按音量加/长按下一曲 ④ 音频输入口 ⑤ 蓝牙/充电指示: 蓝灯闪烁表示等待连接, 蓝灯常亮表示已连接设备; 充电时亮红灯, 充满自动熄灭;</p> <p>开关机 长按  键开机, 再次长按可关机, 如长时间无连接会自动关机。</p> <p>蓝牙连接 在手机上找到设置项进入蓝牙模式, 打开蓝牙设置, 查找设备以找到本机设备名M15点击选中并连接上, 成功连接后蓝牙指示灯会停止闪烁变为常亮。</p> <p>TF卡播放 插入TF卡, 音箱会自动播放TF卡上的音乐。如在其他模式下长按  键转到MP3模式下播放TF卡上的MP3音乐。</p> <p>AUX模式 将3.5毫米音频电缆插入扬声器底部的Aux插孔, 然后通过另一个端口将其连接到音频设备, 例如手机或计算机。</p>	<p>蓝牙对箱配对 两台音箱开机后按其中一台的  键两次, 音箱会寻找另一台配对, 配对成功后发现轻快的提示音, 此时再连接蓝牙可以两台一起播放音乐, 控制其中一台可以调节两台的音量大小。</p> <p>规格参数</p> <table border="1"> <tr><td>电池类型:</td><td>锂电池18650</td></tr> <tr><td>蓝牙版本:</td><td>V5.0</td></tr> <tr><td>连接范围:</td><td>10M</td></tr> <tr><td>充电时间:</td><td>2小时</td></tr> <tr><td>工作电压:</td><td>3.7V</td></tr> <tr><td>充电电压:</td><td>5V</td></tr> <tr><td>防水等级:</td><td>IPX7</td></tr> <tr><td>电池容量:</td><td>1800mAh</td></tr> <tr><td>失真度:</td><td>≤0.5%</td></tr> <tr><td>重量:</td><td>245g</td></tr> </table> <p>常见问题与事项</p> <p>无法打开扬声器: 检查扬声器是否有电源, 如果没有电源, 请先充电。</p> <p>无法与蓝牙设备连接: 检查扬声器是否与第三个蓝牙设备连接, 如果是, 请先断开连接, 如果仍然无法连接, 请重新启动并重试。</p>	电池类型:	锂电池18650	蓝牙版本:	V5.0	连接范围:	10M	充电时间:	2小时	工作电压:	3.7V	充电电压:	5V	防水等级:	IPX7	电池容量:	1800mAh	失真度:	≤0.5%	重量:	245g	<p>【保修服务 12个月】</p> <p>为了维护您的权益, 请仔细阅读本保修条例, 您将享受到我们为您提供的售后服务。</p> <p>一、为给您提供更好的售后服务, 我们承诺:</p> <ol style="list-style-type: none"> 1. 自购买之日起12个月内, 若产品出现质量问题, 我们将提供免费维修, 并保持产品及配件、随机资料的完整, 符合免费保修范围的产品, 无需维修费用, 来回运费由买家自行承担。 2. 具体退货或换货时效及流程请以当前的购买平台为准。您也可以直接联系我们售后支持团队。 <p>二、在保修期内, 有下列情况之一, 我们将不提供售后服务</p> <ol style="list-style-type: none"> 1. 人为引起的故障, 包括: <ul style="list-style-type: none"> 因使用/维护/保管不当或不按说明操作而引起的故障。 自行拆装产品或非我们生产基地的修理而引起的故障。 2. 因不可抗力(如火灾、水灾、地震等)引起的故障。 3. 无法提供购买凭证, 或擅自修改购买凭证。 <p>三、联系方式 更多的保修信息, 请访问 http://www.figmasu.com.cn/</p> <p>本产品经我公司品质控制部门检验其性能参数符合技术标准准许出厂</p> <p>检验员 </p>	<p>Instructions</p>  <p>① Turn ON/OFF Play/Pause/Answer ⑥ Charging Port ② Short Press Volume Down / LongPress Previous Song ⑦ TF Card ③ Short Press Volump Up / LongPress Next Song ④ Audio Input Port ⑤ Bluetooth Indicator/ Charging IndicatorLED: The blue light flashes to indicate that the connection is waiting, and the blue light is always on to indicate that the device is connected. The red light is on when charging, and it is automatically turned off when it is full</p> <p>Turn ON/OFF Long press  button to turn on and long press it again to turn it off. If the no connection for a long time, the speaker will automatically shut down.</p> <p>Bluetooth Connect On the phone, find the settings and then enter the bluetooth model, open the bluetooth settings, find the M15 and click on the connection. After successful connection, the blue indicator will stop flashing and become steady.</p> <p>TF Card Playback Insert the TF card and the speaker will automatically play the music on the TF card. If you press the  button in other modes, you can transfer MP3 music on the TF card in MP3 mode.</p>	<p>产品保証条項</p> <p>顧客の権利と利益を守るために、本条項を丁寧にお読みください。 品質の高いアフターサービスをご提供させていただきます。</p> <p>1. 無料対応</p> <ul style="list-style-type: none"> ●ご購入日から30日間以内に音質/外観/機能がご期待に添えない場合。 ●ご購入日から12ヶ月以内に、商品本体自身の品質に問題が発生した場合。 <p>上記の場合、メール頂ければ、日本語専門のスタッフが24時間以内に解決方法をご提供いたします。(修理/返品/返送の郵便料の提供、返金/再送など)</p> <p>2. 連絡方法</p> <ul style="list-style-type: none"> ●方法①: [アカウントサービス] - [注文履歴] - [出品者に連絡する] ●方法②: figmasu@outlook.com (※注文番号が保証書の代わりとなります) <p>3. 次の場合は保証期間内でも、アフターサービスを提供できません。</p> <ul style="list-style-type: none"> ①人為による故障: 使用上の誤り、不当な修理や保管による故障。 ②自分で取り外し又は弊社以外の場所での修理による故障。 ③火災、公害などでの天災地変による故障と損害。 <p>検査員: </p> <p>本品は弊社の品質部門で検査し、技術基準に適合、合格を致しました。</p>
Battery Type:	Lithium Polymer Batteries 18650																																												
Bluetooth Model:	V5.0																																												
Effective Range:	10 Meter/33FT																																												
Charging Time:	2hours																																												
Working Voltage:	3.7V																																												
Input voltage:	5V																																												
Waterproof:	IPX7																																												
Battery Capacity:	1800mAh																																												
Distortion:	≤0.5%																																												
Weight:	245g																																												
电池类型:	锂电池18650																																												
蓝牙版本:	V5.0																																												
连接范围:	10M																																												
充电时间:	2小时																																												
工作电压:	3.7V																																												
充电电压:	5V																																												
防水等级:	IPX7																																												
电池容量:	1800mAh																																												
失真度:	≤0.5%																																												
重量:	245g																																												
<p>FAQ</p> <p>Fail to turn on the speaker: Check if the speaker has power. Try to charge it and try again later.</p> <p>Fail to connect bluetooth devices: Check if it is connected to a other Bluetooth device. If so, please disconnect it and try again. It is still not workable, please try to restart the speaker.</p> <p>Warranty Service Please read the following terms carefully to protect your rights. You are ensured to have our best after sales service</p> <p>1. Free return/exchange conditions</p> <ul style="list-style-type: none"> ● The appearance/function does not meet your expectations within 30 days from the date of purchase ● Any quality problems of the products within 12 months from the date of purchase. In the above cases, please email Figmasu Customer Service Team and we will provide a solution within 24 hours. <p>2. How to contact us?</p> <ul style="list-style-type: none"> ● ①: Please click the store name on the product page, then click "Ask a question" button to contact us. ● ②: [Account Service] - [Order History] - [Contact Seller] ● ③: figmasu@outlook.com <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment</p>	<p>FAQ</p> <p>Fail to turn on the speaker: Check if the speaker has power. Try to charge it and try again later.</p> <p>Fail to connect bluetooth devices: Check if it is connected to a other Bluetooth device. If so, please disconnect it and try again. It is still not workable, please try to restart the speaker.</p> <p>Warranty Service Please read the following terms carefully to protect your rights. You are ensured to have our best after sales service</p> <p>3. After-sales service cannot be provided even under the warranty period under the following conditions.</p> <ul style="list-style-type: none"> ① Damage caused by personal reasons: Product failure due to improper repair or storage Product failure due to self-demolition or repair ② Product failure by force majeure (fire, flood, earthquake and so on) <p>Inspectors </p> <p>This product has been tested by our company's quality control department and its performance parameters are in compliance with technical standards.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation</p> <p>This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the device and receiver. - Connect the device into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment</p>	<p>使用説明</p>  <p>① 再生/一時停止/受話 ⑥ 充電ポート ② 短押しで音量減少/長押しで曲戻り ⑦ MicroSDカード ③ 短押しで音量増加/長押しで曲スキップ ④ AUX入力 ⑤ Bluetooth/充電ランプ: 青ランプ点滅: 接続待ち 青ランプ点灯: 接続完了。充電中は赤ランプが点灯/充電完了は消灯</p> <p>電源オン/オフ ①ボタンの長押しで電源オン/オフ、長時間接続しないと自動で電源オフ。</p> <p>Bluetooth接続 電源を入れてから、スマホのbluetooth検索機能を起動し、デバイス欄に「M15」を選択すると、接続ができます。接続完了すると青ランプが点灯。</p> <p>AUXモード スピーカー下面のAuxジャックに3.5mmオーディオケーブルを挿入し、携帯電話やコンピューターなどのオーディオデバイスに他のポートで接続します。</p>	<p>2台で同時接続(TWS) 2台のスピーカーをオンにします → その中の1台の  ボタンを連続2回クリック → 通知音が出ると接続が完了です</p> <p>仕様</p> <table border="1"> <tr><td>電池タイプ:</td><td>リチウム電池18650</td></tr> <tr><td>Bluetooth:</td><td>V5.0</td></tr> <tr><td>接続範囲:</td><td>10メートル</td></tr> <tr><td>充電時間:</td><td>2時間</td></tr> <tr><td>動作電圧:</td><td>3.7V</td></tr> <tr><td>充電電圧:</td><td>5V</td></tr> <tr><td>防水レベル:</td><td>IPX7</td></tr> <tr><td>電池容量:</td><td>1800mAh</td></tr> <tr><td>ノイズ:</td><td>≤0.5%</td></tr> <tr><td>重量:</td><td>245g</td></tr> </table> <p>よくある問題点</p> <p>電源が入らない: ちゃんと充電してください。(充電中は赤ランプが点灯)</p> <p>Bluetooth接続できない:</p> <ul style="list-style-type: none"> ①ほかのデバイスとの接続を切ってから、試してみてください。 ②再起動してから試してみてください。 	電池タイプ:	リチウム電池18650	Bluetooth:	V5.0	接続範囲:	10メートル	充電時間:	2時間	動作電圧:	3.7V	充電電圧:	5V	防水レベル:	IPX7	電池容量:	1800mAh	ノイズ:	≤0.5%	重量:	245g																						
電池タイプ:	リチウム電池18650																																												
Bluetooth:	V5.0																																												
接続範囲:	10メートル																																												
充電時間:	2時間																																												
動作電圧:	3.7V																																												
充電電圧:	5V																																												
防水レベル:	IPX7																																												
電池容量:	1800mAh																																												
ノイズ:	≤0.5%																																												
重量:	245g																																												