


Model: 4500521-5



Model: 4500521-8






Model: 4500521-10




Model: 4500521-9



Model: 4500521-12






Model: 4500751



Model: 4500741



Model: 4500741-1





Remote Control Pairing :

- 1.Unplug the power plug.
- 2.Press and hold the stop button until the light flashes.
- 3.Hold the remote control close to the product and insert the power plug.
- 4.Indicator light stops flashing and constant on.
- 5.Pairing success.

Model: 4500801



Model: 4500821





Model: 4500811



Model: 4500831

