

80克双胶纸 单色 双面印刷 风琴折
64*80mm

正面（英文）

80mm

64 mm

User Manual

GT4

Langsdom®

TWS Dual Driver Earphone

We appreciate you for purchasing the Langsdom GT4 TWS Dual Driver Earphone, the following instructions will guide you to use it easily.

Wearing

Put the earphone in your ears, rotate and adjust it to the best angle, Be sure to wear comfortably and secure fit.

Accessories

User Manual Charging Cable Ear caps Qualified Certificate

01

Diagram

① Smart touch ② Transparent cavity ③ LED Indicator ④ Charging port

Earphone:

① Smart touch ② Transparent cavity

Charging box:

③ LED Indicator ④ Charging port

Auto On/ Off

1. When open the box, the earphone will automatically power on.

2. When putted in and close the box, the earphone will automatically power off.

02

Manually On/Off

1. Long press the earphone touch areas about 5s to power on the earphone.

2. Long press the earphone touch areas about 5s to power off the earphone.

Pairing

1. Taking the earphone out of the charging box, the left and right earphone will automatically connect and enter the Bluetooth search pairing state, select and connect "GT4" devices in the Bluetooth list of smart devices.

03

Auto pairing

1. Taking it out of charging box, the earphone will automatically connect back to the last Bluetooth device.

2. When the earphone is disconnected from the device beyond the effective distance, they will automatically reconnect after returning to the effective distance within 1 minute.

Touch Control

Left:

Play/Pause x1
Volume down x2
Long press 2s-3s: Previous song
Enter/Exit game mode x3

Right:

Answer/Hang up x1
Volume up/Reject x2
Long press 2s-3s: Next song
Voice assistant(Siri) x3

Note: The operation of the play/pause function and the call mode can be completed by pressing the left and right ears, and the short press operation requires within 1.5s.

04

Charging

Charging the box:

🟢 Green light's flashing ——— charging
🟢 Green light's on ——— fully charged
🟡 Orange light's flashing ——— Less than 5% battery
🟢 White light's on—open the box
🟡 White light's off—close the box

Charging the earphone:

🟡 Charging box orange light's on ——— charging
🟢 Charging box orange light's off ——— fully charged

Warning

1. Do not listen for a long time at high volume to prevent injury to hearing.

2. Do not wear earphone while driving, cycling or walking, otherwise it will easily cause traffic accidents.

3. The earphone only can be charged with 5V charger, using a fast charger that more than 5V or charger with 5V more than 1.5A which will cause overheat or fire.

4. Please fully charge before long-term placement, and ensure that it is charged every 3 months.

※ It is recommend that new machine be fully charged before use.

05

Service

1. If any problems, please contact with the related stores, our customer service team will answer your questions about the product using and other after-sales issues.

2. Warranty is only covered by the first year of purchase. The intentional damage from users is not included.

3. Please contact us with your order number and earphone's photos by e-mail, because it is helpful for us to solve the problems faster, providing you a better product experience.

Product Parameters

Model: GT4
BT Version: V5.0
Input Voltage: DC5V
Capacity Battery: 40*2mAh/500mAh
BT Frequency Range: 2.402-2.480GHz
Audio Frequency: 20Hz-20KHz
Drivers Size: Ø8mm
Transmission Range: 10m
Sensitivity: 100dB±3dB
Play Time: About 5 hours
Charging Time: About 1.5 hours

06

感谢您使用兰士顿产品
Thanks for choosing langsdom product

背面（中文）

用户手册

GT4

Langsdom®

真无线双动圈耳机

感谢您购买兰士顿GT4真无线双动圈耳机。以下说明将指导您轻松使用它。

佩戴

请将耳机放置耳中，旋转并调整到最佳入耳角度，确保佩戴舒适稳固。

配件

用户手册 数据线 耳帽 合格证

07

产品示意图

① 触控区域 ② 透明腔体 ③ LED指示灯 ④ 充电口

耳机:

① 触控区域 ② 透明腔体

充电仓:

③ LED指示灯 ④ 充电口

自动开关机

1. 打开充电仓，耳机自动开机。

2. 将耳机放回充电仓并关盖，耳机自动关机。

08

手动开关机

1. 在关机状态下，分别长按左右耳机触控区域约5秒，耳机开机。

2. 在开机状态下，分别长按左右耳机触控区域约5秒，耳机关机。

配对

1. 首次使用耳机时，从充电仓中取出耳机，左右耳机将自动连接，然后进入蓝牙搜索配对状态，在智能设备蓝牙列表，选择"GT4"连接即可。

09

自动回连

1. 从充电仓中取出耳机，将自动回连最后一次连接过的设备；

2. 当耳机与设备超出有效距离断开连接后，在1分钟内回到有效距离内，耳机将自动重新连接。

耳机操作说明

左耳:

单击: 播放/暂停
双击: 减音量
长按约2-3秒松手: 上一曲
三击: 进入/退出游戏模式

右耳:

单击: 接听/挂断
双击: 加音量/拒接
长按约2-3秒松手: 下一曲
三击: 唤醒Siri

注意: 其中播放/暂停功能及通话模式下的操作任意按左右耳都可以完成，短按操作要求在1.5秒内完成。

10

充电

充电仓充电:

🟢 绿灯闪烁 ——— 充电仓充电中
🟢 绿灯常亮 ——— 充电仓充满电
🟡 橙灯闪烁 ——— 充电仓电量低于5%
🟢 开盖白灯常亮 🟡 关盖白灯熄灭

耳机充电:

🟡 充电仓橙灯常亮 ——— 耳机充电中
🟢 充电仓橙灯熄灭 ——— 耳机充满电

警告

1. 不要长时间高音量听，以防止听力受损；

2. 驾车，骑车或步行时请不要戴耳机，否则很容易造成交通事故；

3. 耳机只能用5V电压的充电器充电。使用超过5V的快速充电器/使用5V大于1.5A的充电器充电，可能会造成过热/起火；

4. 请在长期放置之前充满电，保障每3个月充电一次。

※ 建议新机在使用前先充满电

11

真诚为您服务

1. 有任何问题，请与卖家联系，我们的售后团队将回答您关于产品使用的任何问题；

2. 提供相应店铺声明的保修服务。当然，不包括故意损坏；


3. 联系我们时，最好一起提供您的订单号和耳机拍照，因为这有助于我们更快地解决问题，为您提供更好的购物体验。

产品规格

型号: GT4
蓝牙版本: V5.0
输入电压: DC5V
电池容量: 40*2mAh/500mAh
传输频率: 2.402-2.480GHz
音频频率: 20Hz-20KHz
喇叭: Ø8mm
传输范围: 10m
灵敏度: 100dB±3dB
播放时长: 约5小时
耳机充电时长: 约1.5小时

12

www.langsdom.com

	日期	2021-1-29	设计部		产品部		市场部	渠道部	董事长审批	
	项目	GT4说明书								

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction