


Get to know your Smart Soap Dispenser




Indicator light colors

Setup

-  Blue flashing: Ready for setup
-  Blue solid: Setup complete


Battery

-  Green: Fully charged
-  Orange: Charging



Getting started


Add liquid hand soap



Make sure the device is powered off.



Turn the lid 45 degrees counterclockwise to open.



Fill liquid hand soap of your choosing to the MAX line.

Note: filling above MAX line can cause spillage.



Turn the lid 45 degrees clockwise to close.

If you're not setting up your device with Alexa, you can turn it on and start using it now. If you are, continue to step 2 before using the dispenser.

How does dynamic dispensing work?

Place your hand farther from the nozzle for more soap and closer for less. A few seconds after dispensing, the 20-second timer will begin.



FCC Regulations:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.