

Non usare detergenti speciali per pulire l'unità;
possono essere usati detergenti senza sapone.
Per le macchie che non sono facili da rimuovere,
si raccomanda di strofinare con alcol

I. Sicurezza e certificazione.



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of substances.

Veuillez lire attentivement le manuel pour une meilleure expérience

A. Dispositifs de liaison

a. Télécharger et installer

Téléchargez en scannant le code ou en cherchant dans InxFIT APP comme suit.



IOS 10.0+



Andriod 6.0+



Bluetooth 5.0

Note : La plate-forme du système d'équipement doit répondre aux exigences suivantes

1. Scannez le code QR ci-dessous pour le télécharger




2. Ouvrez la boutique d'applications mobiles et recherchez "InxFIT" pour télécharger l'application.

b. Méthode de liaison


(Note : Pendant le processus de connexion , InxFIT demandera à votre téléphone d'activer la fonction Bluetooth et autorisera InxFIT à accéder au GPS de votre téléphone.

S'il y a une exception pour les utilisateurs d' IOS qui pratiquent le tethering, veuillez d'abord ignorer cet appareil dans la liste Bluetooth de votre téléphone

1. Cliquez sur "+" dans le coin supérieur droit de la page d'accueil de l'application et sélectionnez "Ajouter un appareil" pour rechercher
Trouvez l'appareil qui correspond à votre montre dans la liste de recherche et tapez dessus pour l'attacher.




2. Cliquez sur "+" dans le coin supérieur droit de la page d'accueil de l'application et sélectionnez "Swipe"
Scannez le code QR affiché sur l'appareil la première fois que vous l'allumez, ou si vous le quittez accidentellement, cherchez-le sur la page des réglages de l'appareil



B. Synchronisation des données

La montre génère et enregistre vos différentes données lorsque vous la portez, et vous devez vous assurer que l'appareil est lié à l'appli avant de procéder à la synchronisation.

Cela se fait comme suit. Ouvrez l'application InxFIT - faites glisser la page vers le bas - la synchronisation commence avec l'invite de synchronisation et la progression




Note : Veuillez synchroniser vos données au moins une fois tous les 7 jours pour éviter l'écrasement des données lorsque la mémoire est pleine

C. Instructions d'utilisation

a. Schéma de chargement


Veuillez connecter et charger l'appareil en suivant les instructions de l'image. Lors de la première mise en service, il est recommandé de charger et d'allumer l'appareil.



b. Port et ajustement


1. Porter (comme des accessoires)

Veuillez garder la montre à un doigt de l'os de votre poignet et ajuster la longueur du bracelet pour qu'il soit confortable.



2. Changer la courroie

Poussez le commutateur latéralement pour desserrer et retirer la sangle.



Note : Un port trop lâche ou trop serré peut affecter la précision des tests de fréquence cardiaque ou d'oxygène dans le sang

D. Instructions d'utilisation

a. Opération clé


Appui court sur le bouton : retour à la numérotation /
commutation entre la numérotation et la liste des fonctions

Bouton de pression longue : Marche/Arrêt









b. Remplacer le cadran

Appuyez longuement sur l'écran de numérotation, la liste de sélection de numérotation apparaît après vibration, faites glisser horizontalement pour sélectionner votre numéro préféré et cliquez pour le changer.



c. Fonctionnement de l'interface





Faites glisser dans les différentes interfaces, chacune montrant, par exemple, l'image suivante :



F. Aperçu de la fonction

1. Caractéristiques

Exercice / Rythme cardiaque / Oxygène sanguin / Sommeil / Réveil /
Exercice de respiration / Minuteur / Météo / Contrôle de la musique / Chronomètre



Note : La fonction météo doit être ouverte dans l'application pour fonctionner correctement. Plus de détails sur les fonctionnalités sont disponibles sur l'application.

2. Activer la campagne

- Démarrer l'exercice : cliquer sur l'icône de la fonction d'exercice - sélectionner le type d'exercice - après le compte à rebours, détecter les données de l'exercice
 - Contrôle du mouvement.
Mettez le mouvement en pause - appuyez brièvement sur le bouton latéral.
Reprendre le mouvement : appuyez brièvement sur le bouton latéral ou touchez le bouton Continuer sur l'écran
 - Pour mettre fin à la campagne : appuyez sur le bouton latéral et maintenez-le enfoncé ou faites une pause et sélectionnez le bouton de fin à l'écran
-

G. Spécifications du produit

Modèle	N23	Type d'écran	1.55 inch
Capacité de la batterie	260mAh	Tension de charge	5V
Temps de charge	Environ 2 heures	Version Bluetooth	5.0
Niveau d'étanchéité	IP68	Mode de charge	Charge magnétique
Température de fonctionnement	-20°C-45°C	Taille de la montre	H: 253.8 W: 34.6 D: 12.17
iOS	IOS 10.0+		
Android	Android 6.0+		

Note : Ne portez pas l'appareil pour prendre un bain ;
les températures élevées ou la vapeur peuvent endommager l'appareil.

H. Nettoyage et entretien



Il est recommandé de porter et de nettoyer les produits en respectant les trois points suivants.

1. Maintenir les produits propres
2. Maintenir les produits au sec
3. Ne le portez pas trop serré

N'utilisez pas de nettoyeurs spéciaux pour nettoyer l'appareil ;
vous pouvez utiliser des nettoyeurs sans savon.
Pour les taches qui ne sont pas faciles à enlever,
il est recommandé de frotter avec de l'alcool

I. Sécurité et certification.



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of substances.

Please read the manual carefully for a better experience

A. Binding devices

a. Download and install

Download by scanning the code or searching the InxFIT APP as follows.



IOS 10.0+



Andriod 6.0+



Bluetooth 5.0

Note: The equipment system platform needs to meet the requirements

1. Scan the QR code below to download




2. Open the mobile app store and search for "InxFIT" to down load the app.


b. Binding method

- (Note: During the tethering process InxFIT will prompt you to turn on the phone's Bluetooth and authorize InxFIT to access the GPS on your phone.
If there is an exception for IOS users tethering, please ignore this device in your phone's Bluetooth list first)

1. Click "+" in the top right corner of the app home page and select "Add Device" to search. Find the device that corresponds to your watch in the search list and tap to tether it.




2. Click "+" in the top right corner of the app home page and select "Swipe" Scan the QR code displayed on the device the first time you turn it on, or if you accidentally exit, look for it on the device-Settings-About page



B. Data synchronization

The watch will generate and record your various data while you are wearing it, and you need to make sure the device is tied to the app before syncing.

This is done as follows. Open the InxFIT App - drag down the page-sync starts with sync prompt and progress




Note: Please sync your data at least once in 7days to avoid data overwriting when the memory is full

C. Instructions for use

a. Charging schematic


Please connect and charge the device according to the picture instructions. When starting up for the first time it is recommended to charge and turn on.



b. Wearing and adjustment


1. Wear (as accessories)

Please keep the watch one finger away from your wrist bone and adjust the strap length to a comfortable fit.



2. Changing the strap

Push the switch sideways to loosen and remove the strap.



Note: Wearing too loosely or too tightly may affect the accuracy of heart rate or blood oxygen testing

D. Operating Instructions

a. Key operation


Short press on the button: back to the dial / switch between dial and function list

Long press button: On/Off








b. Replace the dial

Long press on the dial screen, the dial selection list appears after vibration, swipe horizontally to select your favorite dial and click to change it.



c. Interface operation


Swipe the interface to enter different interfaces, the various interfaces are shown as follows:



F. Function Overview

1. Features

Exercise / Heart Rate / Blood Oxygen / Sleep / Alarm Clock /
Breathing Exercise / Timer / Weather / Music Control/ Stopwatch



Note: The weather feature needs to be opened on the app to work properly.
More feature details are available on the app.

2. Turn on the campaign

- Start exercise: click on the icon of the exercise function-select the type of exercise-after the countdown starts to detect the exercise data
- Motion control : Pause the movement-short press the side button.
Resume movement : Press the side button briefly or tap the continue button on the screen
- To end the campaign: press and hold the side button or pause and select the end button on the screen

G. Product specifications

Model	N23	Screen type	1.55 inch
Battery capacity	260mAh	Charging voltage	5V
Charging time	About 2 hours	Bluetooth Version	5.0
Waterproof level	IP68	Charging mode	Magnetic charge
Operating temperature	-20°C-45°C	Watch size	H: 253.8 W: 34.6 D: 12.17
iOS	IOS 10.0+		
Android	Android 6.0+		

Note: Do not wear the device for bathing; high temperatures or steam can damage the device.

H. Cleaning and maintenance



It is recommended that products be worn and cleaned in accordance with the following three points.

1. Keeping products clean
2. Keep products dry
3. Don't wear it too tight

Do not use special cleaners to clean the unit; soap-free cleaners can be used. For stains that are not easy to remove, it is recommended to scrub with alcohol

I. Safety and certification (see the certificates).



The device meets the EU ROHS criterion.
Please refer to IEC 62321, EU ROHS
Directive 2011/65/EU and revised directive.

This device complies with Part 15 of the FCC Rules. Operation
subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received,
that may cause undesired operation.

Changes or modifications not expressly approved by the
party responsible for compliance could avoid the user's
authority to operate the equipment. This equipment has
been tested and found to comply with the limits for a Class
B digital device, pursuant to Part 15 of the FCC Rules. These
limits are designed to provide reasonable protection
against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio
frequency energy and, if not installed and used in
accordance with the instructions, may cause harmful
interference to radio communications. However, there is no
guarantee that interference will not occur in a particular
installation.

If this equipment does cause harmful interference to radio
or television reception, which can be determined by turning
the equipment off and on, the user is encouraged to try to
correct the interference by one or more of the following
measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
receiver.
- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician
for help.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.



Old electrical appliances must not be
disposed of together with the residual
waste, but have to be disposed of
separately. The disposal at the communal
collecting point via private persons is for
free. The owner of old appliances is
responsible to bring the appliances to these
collecting points or to similar collection
points. With this little personal effort, you
contribute to recycle valuable raw materials
and the treatment of toxic substances.