

Internal Photographs


Alcotek, Inc. TILT Angle Sensor
Model F-000409-01 Operator Interface



Inside Bottom of EUT

Internal Photographs


Alcotek, Inc. TILT Angle Sensor
Model F-000409-01 Operator Interface



Inside Assembly

Internal Photographs


Alcotek, Inc. TILT Angle Sensor
Model F-000409-01 Operator Interface



Bottom of PBC Board with battery

Internal Photographs


Alcotek, Inc. TILT Angle Sensor
Model F-000409-01 Operator Interface



Bottom of PC Board with Battery Removed

Internal Photographs


Alcotek, Inc. TILT Angle Sensor
Model F-000409-01 Operator Interface



Top of PC Board

Internal Photographs

Alcotek, Inc. TILT Angle Sensor
Model F-000409-01 Operator Interface



Side of PC Board