

# BOLOXA

## Pair with Other Device

A17 sports earbuds have memory connect function, they usually auto-connect with the last paired device. Thus, if you want to connect them with other devices, you should disconnect "A17" from the last paired device, then search and connect it on your another device.

## Earbuds Charging

Insert A17 Earbuds into the charging case properly, they will power off and get charged automatically.

When being charged, the display icons will flash up and down, and the earbud's LED light will flash red. When fully charged, the display icons and the earbuds' LED red light will turn off. Earbuds' LED light

## Charging Case Charging

Use the provided Type-C cable (placed in the black accessory box) to charge the charging case.

During charging, the charging case power display will show the battery in real time. The number will be displayed as "100" when fully charged.

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux RF. L'appareil peut être utilisé en condition d'exposition portable sans restriction.

## IC Warning

This device complies with Industry Canada's license-exempt RSS. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. »

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux RF. L'appareil peut être utilisé en condition d'exposition portable sans restriction.

## Factory Restore Settings

This action will delete the pairing data between earphones and your devices. When the earbuds had been connected with multiple devices, you don't know which one is the last device, you can do this operation.

## How to sync volume on Android?

To protect users from potential hearing damage, Android's limit on max volume is quite low for Bluetooth audio devices.

If you feel the volume is too low, please access developer options and enable absolute volume, so you'll be able to max the volume at your own volition and to the full capabilities of your Bluetooth earbuds.

(Please scan this QR code to watch a video to learn more details.)

## Safety Attention

- Using earbuds at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at times for your safety.
- Please keep the earbuds out of extreme heat or humidity, do not use any corrosive cleaner/acid to clean the earbuds.
- Please avoid disassemble/reassemble the product in case of failure or fire accident.
- Please keep beyond the reach of kids or pets.

尺寸: 89\*90mm  
材质: 157g铜版纸, 覆哑膜  
对折方式: 风琴折