

FIGURE 7
LED LAMP (G117P38MO6C)
COVER REMOVE




FIGURE 8
LED LAMP (G117P38MO6C)
MAINBOARD FRONT




FIGURE 9
LED LAMP (G117P38MO6C)
MAINBOARD BACK




FIGURE 10
LED LAMP (G117P38MO6C)
LED FRONT




FIGURE 11
LED LAMP (G117P38MO6C)
LED BACK




FIGURE 12
LED LAMP (G117P38MO6C)
CONTROL BOARD FRONT




FIGURE 13
LED LAMP (G117P38MO6C)
CONTROL BOARD BACK




FIGURE 14
LED LAMP (G117P38MO6C)
CHIP & CRYSTAL ON BOARD



-END-