

1 Product Function

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1.1 Remote and collar

(1) Low Shock Button: Press the button, the collar will emit shock of low power except shock switch is off.

(2) Medium Shock Button: Press the button, the collar will emit shock of medium power except shock switch is off.

(3) High Shock Button: Press the button, the collar will emit shock of high power except shock switch is off.

Note: Shock button will be worked once in 10 seconds.

(4) Vibration Button: Press the button, the collar will emit vibration of much times ejection.

(5) Sound Button: Press the button, the collar will emit the sound of beeps.

(6) Power Button: Short press the button to activate the collar. Long press the button to shut down the power of the collar.



1.2 Phone

Note: BLE version of phone(ios or android) is above 4.2

The collar is controlled not only by remote, also by the apple phone or sorts of android phones.


Open the app of lindopet, then start to ble scan. Show the list of lindopet collar on scanning end, select your collar and click it to connect the collar.



The system show the control page and setting page of the collar until it is connected.



The buttons function is the same as remote's, but shock switch button is new function. Shock command does not work as shock switch is off.



Push the setting tab to switch to the setting page and change the sorts of settings of collar. The collar's name can be named for your dog's name.

You can change the level of five mode(Low shock mode, medium shock mode, high shock mode, vibration mode, sound mode) and save the value into the collar.

Pair mode is used to make a pair the remote and the collar. When pair mode is on, the remote can send a command to the collar to complete the pairing operation.

2 How to use

Note: Please charge before using the product.

- (1) Install a button battery on the remote.
- (2) Connect the charger cable to the charging port of the collar and plug the charger into a standard wall outlet.
- (3) The blue light of power led will flash on the collar until the light indicates charging is completed.
- (4) Press the logo button(power button)on the collar to start.
- (5) Press a button of the remote to verify the connect of the remote and the collar.
- (6) Start the "lindopet" APP of a phone to search the collar and connect it.

3 How to choose the appropriate level for dogs

The size of a dog	15-30LBS	31-50LBS	51-80LBS	>80LBS
Static Shock Level	Low Shock (0-4)	Medium Shock (5-9)	High Shock (10-12)	High Shock (13-15)
Vibration Level	0-2	3-5	6-8	8-9
Sound Level	0-2	3-5	6-8	8-9

Note: Please select the appropriate level according to the size of a dog.

4 Important information

- (1) Place the collar on your dog at the beginning without starting to allow your dog to adapt.
- (2) Keep the collar close to the neck skin of your dog.
- (3) Avoid wearing the collar on the dog for more than 12 hours a day. If possible, reposition the collar every 1 to 2 hours.
- (4) Remove the collar before swimming or bathing.