

BLUETOOTH SPEAKER STAINLESS STEEL VACUUM CUP

USER MANUAL

1 Important Notes



- Please read this manual carefully before use.
- Remove speaker from the tumbler body before washing.
- Please charge speaker with power adapter(output rated voltage 3.2-4.2V).
- Charge in full before first use.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
- USB Cable included for charging only .

2 Product parameter

Product Model	L20
Product Size	95X200mm
Cup capacity	17OZ
Cup Material	Food grade 304 stainless steel
Battery Capacity	500mAh
Charging Method	Micro USB
Charging Time	<1h
Bluetooth Range	≤ 10m

3 Connecting Your Device

- Turn on bluetooth speaker by pressing and holding
- Turn your bluetooth device on search mode. Find device titled "L20" and select.
- Once a connection with media device has been established, "connected" will sound.

Note: When there is no Bluetooth connection, the device will automatically shutdown after 5 minutes.

- When cleaning the water cup, please remove the speaker from the water cup first to avoid damage to the speaker.
- Double-click the callback and click Cancel the callback.

- When cleaning the water cup, please remove the speaker from the water cup first to avoid damage to the speaker.
- Double-click the callback and click Cancel the callback.

- When cleaning the water cup, please remove the speaker from the water cup first to avoid damage to the speaker.
- Double-click the callback and click Cancel the callback.

- Hand wash tumbler recommended.
- Use non-abrasive cleaner.
- To clean speaker, wipe with a damp cloth.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

4 Function Description

- Long press volume down ; Short press previous song.
- Long press to turn on/ off ; Short press play/pause.

- When calling Short press answer, Short press end; Double click refuse.

- When cleaning the water cup, please remove the speaker from the water cup first to avoid damage to the speaker.
- Double-click the callback and click Cancel the callback.

- When cleaning the water cup, please remove the speaker from the water cup first to avoid damage to the speaker.
- Double-click the callback and click Cancel the callback.

- Hand wash tumbler recommended.
- Use non-abrasive cleaner.
- To clean speaker, wipe with a damp cloth.

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

5 Power Recharging

- Connect the USB cable included to charge your bluetooth speaker tumbler through computer USB port or power adapter.

Low Power Warning: When voltage is lower than 3.3V, "low battery please charge" will sound. Please charge as soon as possible.

- When cleaning the water cup, please remove the speaker from the water cup first to avoid damage to the speaker.
- Double-click the callback and click Cancel the callback.

- When cleaning the water cup, please remove the speaker from the water cup first to avoid damage to the speaker.
- Double-click the callback and click Cancel the callback.

- Hand wash tumbler recommended.
- Use non-abrasive cleaner.
- To clean speaker, wipe with a damp cloth.

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

6 Cleaning Instructions