


Smart Speaker

Wireless bluetooth Coffee table speaker

—USER'S MANUAL—



Dear:

Hello, thank you for purchasing and using smart home products. To ensure your legal rights, we recommend that you read this product manual carefully. If you have any objections and better suggestions to the content of this product or the manual, please contact the company through official WeChat public account, e-commerce platform customer service within 7 days of purchasing the machine, we will be happy to help you service.

Bluetooth:	Bluetooth 5.0
Speaker:	10W*2/20W*1
Audio response:	100HZ-18KHZ
Power adapter:	AC 100-240V DC 12V/1-2A
Charging time:	≈4 hours
Battery life:	≈10 hours (50% volume test data)


Product List



Host X 1




Manual X 1




Oak feet X 3

Button and interface description Bluetooth version



Bluetooth pairing

1. Turn on Bluetooth automatically when power is connected.



Search Bluetooth

2. When the mobile phone's Bluetooth is turned on, Search device GT-AI8A on the phone.



Paired connection

3. The Bluetooth speaker will be paired with the smartphone via Bluetooth technology. Enter the connection pairing password: 1234



Successfully paired and connected

4. After the smartphone is successfully paired, the Bluetooth speaker will emit a tone.



Name and content of toxic substances in the product

Part Name	Toxic substances or elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr6+)	Polybrominated biphenyls (PBB)	Polybrominated Diphenyl Ether (PBDE)
Host	x	o	o	o	o	o
Charger	x	o	o	o	o	o
Battery	x	o	o	o	o	o
Cable	x	o	o	o	o	o

This form is compiled in accordance with SJ/T 11364.

o: Indicates that the content of the hazardous substance in all homogeneous materials of the part is within the limit requirement of GB/T 26572.

x: Indicates that the content of the hazardous substance in at least a certain homogeneous material of the part exceeds the limit requirement of GB/T 26572, and there is no mature alternative in the industry at present, which meets the environmental protection requirements of the EU RoHS directive.



The number in this logo indicates that the environmental protection use period of the product under normal use is 20 years. Some components may also have an environmental protection use period mark, and the environmental protection use period is subject to the identification number.

Common problems and repair methods

The lake cannot be turned on. Connect the power adapter to check whether it is turned on, press the power button to turn on, the indicator light is normal; if the indicator light does not light, please check whether the power adapter is faulty, please contact the manufacturer to send the package, if you assemble it privately, you will be responsible for the consequences:

2. Cannot search the Bluetooth of this unit. Check if there are other devices connected to the Bluetooth of this machine, please click **MOOE** to restore factory settings, and then click on the device to connect to the Bluetooth again;

3. Charge the battery. Please use the 12V/1-2A original power adapter, the charging time is about 4 hours, it will automatically exit the charging state after fully charged; it can also be used in the plug-in state;

4. For wireless charging, please confirm whether the mobile phone has its own wireless charging function, and charge the mobile phone at the sign;

5. If you don't use it for a long time, please turn off the power of this machine and unplug the power adapter:

6. Don't throw away electronic and electrical products at will, so as to avoid battery damage to the environment; don't put it under high temperature or open flame, beware of fire.

Product performance failures caused by non-human damage during the warranty period can enjoy the following three guarantees:

1. This product supports seven days no reason to return or exchange. Within sevendays from the date of purchase, provided that the products, accessories, packagingboxes, invoices and other items sold by the original manufacturer are intact and donot affect their secondary sales, you can choose after the inspection and confirmationby the service point authorized by the manufacturer The items are sent back togetherfor return and exchange;
2. The three-guarantee period for the core components of this host and power adapteris 3 years. This certificate shall not be altered, otherwise it will be regarded asinvalid;

The following situations (including but not limited to) are not within the scope of the "Three Guarantees" service:

1. No "Three Guarantees" vouchers or missing valid invoices, or beyond the "ThreeGuarantees" service validity period;
2. The use of expansion components or peripheral devices that are not approved by the company causes damage to the standard components of the product or causes malfunctions;
3. Parts damage and product performance failure caused by abnormal reasons(including but not limited to foreign objects entering the equipment, transportation and moving bumps in bad environments, etc.);
4. All equipment caused by force majeure such as earthquakes, fires and other natural disasters or accidents (stolen or lost) cannot work normally;
5. Product performance failure caused by violation of the product instruction manual; unauthorized persons disassemble, repair, install or modify by themselves;
6. The product is normally discolored, worn or consumed during use;

CC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

F Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Wireless charging :

Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

After-sales service guarantee card

Product model: **Proof of purchase:**

Purchase Date: Purchase Location:

Phone: _____ Email: _____

Maintenance records: