


MACALLY

IPKBCASE11



Rugged Wireless Keyboard Case with Multi-Touch Trackpad for iPad A16, Detachable Magnetic Snap-On Case, Black

For iPad

MACALLY

Welcome to the Macally family and thank you for purchasing the IPK-BCASE11.

Our mission is to deliver aesthetically pleasing, high-quality and affordable peripherals and accessories to satisfied customers. We do that by creating products that are both innovative and practical but most important easy-to-use.

If you have any questions, feedback, or just want to say hi, please reach out to us at techsupport@macally.com or on any one of our social media channels.

Don't forget to share your setup with us using [#macally](#) and follow us for to get exclusive offers.



MacallyUSA



With Love From Southern California,
Macally


PACKAGE CONTENTS

- iPad Case
- iPad Keyboard
- USB-C to USB-C charging cable
- User's Guide

Model Compatibility

- iPad A16 (11th Gen)

Hardware basics




NOTE

The iPad 11 (A16) cannot charge an Apple Pencil due to its design.

LED Indicators

Power Key and LED

(press and hold the key for 2 seconds to turn on the keyboard or turn it off)



Power LED


- Green
 - Turning the keyboard on (the LED will turn off after 20 seconds when not paired)
- Red:
 - Turning the keyboard off, the LED light turns off
- Blue:
 - Flashing – Bluetooth pairing
 - Solid – Bluetooth paired

Charging LED

- Blinking Red:
 - The keyboard needed to be charged
 - Charging when the keyboard is on Solid Blue
- Solid Red:
 - The keyboard is charging while it's off.
- Solid Blue or no LED lights
 - Solid Blue – Fully charged when keyboard is on.
 - Off – Fully charged when the keyboard is off.
- Active – White
- Not Active – Off

SETUP & INSTALLATION INSTRUCTIONS


1. Detach the magnetic iPad case from the stand and place your iPad into it.




NOTE

The stand is also magnetically attached to the keyboard and can be detached as needed.

2. Place your iPad into the iPad keyboard.



BLUETOOTH PAIRING INSTRUCTIONS




Take a look at the two “light gray keys” labeled “fn” and “Z”. That is how you pair.

1. Open the Bluetooth settings on the device to which you are pairing the keyboard.
2. Hold the “fn” key. While holding it, press “Z” for three seconds.
3. Once the Blue LED on the power LED flashes, tap connect.
4. A pop-up will appear. Tap on “Pair.” The keyboard is now connected.

NOTE

To enable clicking, Tap to Click, tap on settings > general > trackpad > turn on Tap to Click.

CHARGING THE KEYBOARD




To charge the keyboard, plug the USB-C end of the provided cable into any available USB-C port on a USB wall charger, and insert the USB-C end of the cable into the USB-C port located on the top right-hand side of the keyboard.

Battery LED:

- Blinking Red – Charging when the keyboard is on
- Solid Red – Charging while keyboard is off
- Blue – Fully charged when keyboard is on.
- Off – Fully charged when keyboard is off.

KEYBOARD SHORTCUTS



The keys highlighted in grey are shortcuts. They are on by default for iPads. Below is a chart of its functions.



Key	Functions
	Decrease the iPad display brightness level
	Increase the iPad display brightness level
	On-Screen Keyboard on and off (only where you can type)
	Open Spotlight
	Press for Dictation; Hold for Siri
	Previous Track
	Play/Pause
	Next Track
	Mute
	Volume Down
	Volume Up
	Lock your iPad
fn	Switch between multiple input (if you have two different keyboard language) Emoji Viewer (If you have one keyboard language)

KEYBOARD BACKLIGHT AND PAIRING

Press fn key together with the key in the table below:

fn+	Functions
	Pair
	Back light controls, Dim, Bright, Brighter, Off

TRACKPAD AND GESTURES

After pairing with your iPad, keyboard typing should work. Putting one finger on the trackpad should make a gray dot(cursor) appear on the screen. You can use the trackpad to open apps, go to the Home Screen, scroll, zoom, and more. Below is a table of different gestures that Apple iPadOS supports.

NOTE

1. You must first enable “Multitasking & Gestures” in your iPad settings to use full function; 2. If you can’t perform certain gestures on the keyboard trackpad, please try the same gesture on the iPad screen to ensure your iPad OS supports it. Trackpad can do nothing more than iPad’s touchscreen.



Click.
Press with one finger until you feel a click




Click and hold.
Press and hold with one finger.




Drag.
Click and hold an item, then slide your finger across the trackpad to move it.




Wake.
Click the trackpad to wake iPad.
If using external keyboard press any key.



Open the Dock.
Use one finger to swipe the pointer past the bottom of the screen.



Go Home.
Use one finger to swipe the pointer past the bottom of the screen. After the Dock appears, swipe the pointer past the bottom of the screen again.




View Slide Over.

Use one finger to swipe the pointer past the right edge of the screen. To hide Slide Over, swipe right again




Open Control Center.

Use one finger to move the pointer to select the status icons at the top right, then click.



Open Notification Center.

Use one finger to move the pointer to select the status icons at the top left, then click.




Scroll up or down.

Swipe two fingers up or down.



Scroll left or right.

Swipe two fingers left or right.




Zoom.


Place two fingers near each other. Pinch open to zoom in, or pinch closed to zoom out.




Go Home.
Swipe up with three fingers.




Open the App Switcher.
Swipe up with three fingers, pausing before you lift your fingers.



Switch between open apps
Swipe left or right with three fingers.



Open Today View.
When the Home Screen or the Lock Screen is visible, use two fingers to swipe right.



Open search from the Home Screen.
Swipe down with two finger.



Secondary click.
Click with two fingers to show the quick actions menu for items like icons on the Home Screen, messages in a mailbox, and the Camera button in Control Center.

BATTERY & BACKLIGHT USAGE

This keyboard includes a built-in 1500mAh Li-Ion rechargeable battery. When the backlight is not used at all, a fully charged battery will last up to approximately 2-3 months depending on how much the keyboard is used.

It is important to note, however, that the backlight consumes a lot of energy. For the purpose of saving battery power, the keyboard's backlight is automatically turned off at different inactivity time increments based on the set brightness level.

- Brightest level: 30 seconds
- Medium level: 60 seconds
- Low level: 120 seconds

The backlight will automatically turn back on when typing resumes. Typically, a fully charged battery is adequate for one week of backlight use. It may be a good idea to turn on the backlight only at night or in low light environments in order to extend the battery life.

When the battery level is low, its indicator LED will flash red (purple if B1 is in use), so please charge the keyboard using the USB cable provided. The keyboard can still be used while it is charging.

SAFETY INSTRUCTIONS

Please read the following carefully. Incorrect use of this product may result in reduced performance, permanent damage and void your warranty.

- Keep this device away from liquid, humidity and moisture.
- Operate this device only within the specific temperature range of 0°C (32°F) to 5°C to 40°C (104°F)
- Please refrain from taking the device apart. Doing so will void your warranty.
- Do not dispose this product in the garbage. Take it to your local recycling center.

SPECIFICATIONS

Switches	Scissor-key
Battery Size	750mAh
Charge Time	3-5 hours
Work Time	Backlight on: 1 week (approximately)
	Backlight off: 2-3 months
Charging Port	USB-C
Backlight Sleep Time	Brightest level: 30 seconds
	Medium level: 60 seconds
	Low level: 120 seconds
Bluetooth sleep time	60 minutes

Tech support

Tech support hours are from 9:00 AM to 5:00 PM Monday through Friday (PST).

- E-Mail: techsupport@macally.com
- Phone: (909) 230-6888

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition, compliance with exposure requirements.

This equipment should be installed and operated with minimum distance 0 mm between the radiator & your body.

Warranty

Macally Peripherals warrants that this product will be free from defects in title, materials and manufacturing workmanship for one year in North America from the date of the purchase. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, Macally will repair or replace the product. This warranty is exclusive and is limited to the product that this user's guide came with. This warranty shall not apply to products that have been subjected to abuse, misuse, abnormal electrical or environmental conditions, or any condition other than what can be considered normal use. The liability of Macally Peripherals arising from this warranty and sale shall

be limited to a refund of the purchase price. In no event shall Macally Peripherals be liable for costs of procurement of substitute products or services, or for any lost profits, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply notwithstanding any failure of essential purpose of any limited remedy.