

DACHIX





D200 Pro

MAGNETIC GOLF SPEAKER

USER MANUAL


1. Accessory





3.5mm Audio Cable USB Charging Cable

2. Illustration



① Power ON/OFF


② Mode Selection of Bluetooth /Line In / USB Flash Disk / TWS Option

③ Play/Pause/Answer or Reject Phone Call

④ Volume - /Previous Track

⑤ Volume + /Next Track

3. Specifications



⑥ Charging Port ⑦ USB Flash Disk ⑧ AUX IN

Bluetooth	5.0+EDR
Transmission Range	18m/58ft(open area)
Waterproof	IPX7
Output	2*10W
Playtime	Up to 15 hours(50% volume)
Power Supply	DC 5V/1.0A
Battery Capacity	3.7V/3000mAh
Charging Time	About 2.5 hours
Loudspeaker Size	88*40mm
Distortion	<1%
Frequency	80Hz-18KHz
Driver Unit	4010W/53mm
Size	L205*W52*H83mm

4. Function Key

Key	Oper tion	Function
	ON/ OFF	1. Short press to turn on 2. Press 3 seconds to turn off 3. Long press 8 seconds to reset
	MODE	1. Press to selection bluetooth/ USB flash disk/AUX modes 2. Press 2 seconds to enter into the TWS function in the mode of TWS, long press the button 2 seconds to disconnect Answer/Reject call button, short press for answering, long press for rejecting.
	Play/ Pause	1. Press once to decrease to volume. 2. Hold 2 seconds to previous track.
	Vol +/- PREV	1. Press once to increase to volume. 2. Hold 2 seconds to next track

5. LED Indicator

1. Blue LED blinks when the speaker waiting for connection, and turns solid blue after Bluetooth connected successfully.

2. When charging, the red light is shining. When full charged, the red light is always on.

6. Bluetooth Pairing

1. Power on speaker the blue LED will blinks, go to Bluetooth setting on your device, find "D200 Pro" and select to pair.

7. USB Flash Disk/ AUX Mode

1. Max support reading 64GB USB flash disk.

2. Insert any USB flash disk, the speaker will play the audio files in the USB flash disk automatically.

3. Insert the 3.5mm audio cable, the speaker will shift to AUX mode.

8.USB-OUT-1A What is TWS

TWS means ture wireless stereo, Let's say two Bluetooth speakers are able to paired and playing music synchronously.

NOTICE

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. This device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

How to Pair Your Device?

1. Please make sure these two speakers are disconnected from your bluetooth device before you turn them on. Then please turn on two speakers.

2. Long press the matching button for 2 seconds, there will be voice prompt in the mean time, the yellow light will be shinning to enter into the matching mode.

3. When enter into the matching mode with the voice prompt, the yellow light on the two speakers will be bright in the mean time the light control on the main-speaker is normal and the yellow light brighting on the sub-speaker.

4. Select the searching mode on your device. When your device finds "D200 Pro", select it and connect.

5. They will perform as the stereo sounding system.

6. Once the speakers are well paired at the first time, they will be automatically paired next time without the above pairing operation.

7. If you need to remove TWS pairing, press the "M" key for two seconds to remove the TWS team forming function. If you need to pair TWS again, please repeat the above operation.

8. When speakers are paired, only the speaker will answer the phone.

Sportkee Brother LLC

3422 Old Capitol Trail Suite 700 Wilmington,

DE 19808, US

Service email: customerare2@avipmail.net

RoHS

CE

FC



Made in China

说明书工艺：157g铜版纸+过哑胶+彩印