

Exposure Evaluation

AMU37™ 800 PS

Single-Band Medium Power Air Master Unit

FCCID: 2BA6EAMU371PSB21B

Date: June 24, 2025

Model No: AMU37-1-PS-B-21-1N-D0-1



Avari Wireless, Inc.
1400 112th Ave SE, Ste 100
Bellevue, WA, USA 98004
<http://www.avariwireless.com>

© Copyright 2025 Avari Wireless. All Rights Reserved

RF Exposure Evaluation

According to FCC Part 1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensure that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines. More information on evaluating compliance with these limits can be found in the FCC's OST/OET Bulletin Number 65, "Evaluating Compliance with FCC-Specified Guidelines for Human Exposure to Radiofrequency Radiation".

The maximum power density limit allowed for the occupational / uncontrolled exposures for an average time of 30 minutes is frequency and output power dependent. Although the equipment under test is capable of producing a composite output power of up to 38dBm, the overall ERP can't exceed 37dBm. Cable distribution loss and antenna gain needs to be taken into account as part of the design and installation in order not to exceed the maximum 37dBm ERP limit. The table below illustrates the different operating scenarios with maximum allowed output power of 37dBm at the antenna representing worst case scenarios from a RF Exposure point of view.

Freq Band (MHz)	Conducted Output Power (dBm)	Min. Cable Loss (dB)	Max Antenna Gain (dBi)	Max EIRP (mW)	Power Density Limit Allowed (mW/cm ²)	Safe Distance (cm)
800	38	8	7	5012	0.567	27

RF Exposure Evaluation Distance Calculation

$$d = \sqrt{(EIRP/4\pi S)}$$

Where:

d = Distance to the center of radiation of the antenna (cm) for the allowable Power Density

S = Allowable Power Density Limit (mW/cm²)

EIRP = Equivalent isotopically radiated power (mW) = $10^{[TX \text{ Power (dBm)} + Ant \text{ Gain (dBi)}]/10}$

If the antenna will be positioned closer to end users than the required safe distance, then the installer must calculate the power back off required for a given installation using the formulas provided.