



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

PARTS LIST

A x1



B x1



C x1



D x1



E x1




F x1



*If your umbrella is equipped with a remote control.

Before beginning to assemble this product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble this product. Stop and contact our customer service center.


Remove all protective materials on the product before any assembly.




Warning: When the umbrella is flat on the ground or not placed vertically with the ground, if you insert the battery and press the up or down button, the motor will stop working and display the red light.

To set up the umbrella


STEP 1



STEP 2




STEP 3



NOTE:

If you need a weight base, please visit bluu.com.

STEP 4



NOTE:



Please insert the battery according to the direction indicated by the arrow.

DONE!

To open the umbrella

STEP 1

PRESS THE RISE BUTTON.




or



*If your umbrella is equipped with a remote control, just press the rise button on the remote control directly.

WARNING:



When the motor is working, ensure NO barriers around the surroundings and do NOT move the umbrella or touch components with hands.