

SHD-S278-2 通用说明书（英文版）  
75mm\*155mm双面印刷  
材质：250g双铜版纸

SHD-S278v-2 通用说明书（中文版）  
75mm\*155mm双面印刷  
材质：250g双铜版纸

QUICK START GUIDE

SIZE

2.72 in ( 69 mm )

1.14 in ( 29 mm )

3.54 in ( 90 mm )

9.06 in ( 230 mm )

1.26 in ( 32 mm )

3.03 in ( 77 mm )

2.28 in ( 58 mm )

1.14 in ( 29 mm )

ON / OFF

Vibrator :

Remote :

DISTANCE

Remote Control Distance:

5-10m

CHANGE PATTERNS

9 Patterns

1. Hold (on the vibrator) 3s to place it into Standby condition.

2. Hold (on the remote) for 3s to turn on, then press " " switch patterns.

3. Hold " " 3 seconds to pause while vibrating. You can restart the device with the remote directly within 20 minutes, otherwise it will be off. Repeat all above to turn it on.

USB MAGNETIC CHARGING

\*WARNING: Please DO NOT use adaptor with ">5V" output

1. Vibrator

2. Remote :

PRODUCT CLEANING

Clean Please clean product with warm water or antibacterial soap.

Wipe Dry the product with clean cloth or towel.

Store Keep the product in a cool, dry, clean place.

Attention Never clean this product with organic cleaner containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

Do not use it at temperature over 167 °F/75 °C.

Stop using it when any discomfort occurs.

It is recommended to use it with water-based lubricant.

Do not use it if you find the product unsmooth or damaged.

Keep out of reach of children.

产品使用说明书

产品规格

2.72 in ( 69 mm )

1.14 in ( 29 mm )

3.54 in ( 90 mm )

9.06 in ( 230 mm )

1.26 in ( 32 mm )

3.03 in ( 77 mm )

2.28 in ( 58 mm )

1.14 in ( 29 mm )

开/关机

震动器:

遥控:

控制距离

遥控控制距离:

5-10米

切换模式

先长按震动器上电源键3秒使产品处于待机状态后, 或可通过遥控器控制

9 频震动模式

充电模式

\*请使用5V及以下电源适配器;

1. 震动器充电

2. 遥控器

保养与维护

1. 本品仅适合成年人使用, 非避孕用品, 请远离儿童放置。

2. 使用过程中, 请勿过度用力, 请留意避免受伤。

3. 请勿与他人混用本产品。使用过程中如有不适, 请立即停用本品。

4. 须定期检查产品是否损坏, 发现损坏时应立即停止使用。

注意事项

1. 本产品为成人玩具, 未成年人禁止使用;

2. 为了卫生, 建议与避孕套一起使用;

3. 为了保护您娇嫩的肌肤, 建议与润滑剂同时使用;

4. 请将产品存放在阴凉干燥之处;

5. 使用时若产生不适, 请立即停止使用。

155mm

75mm

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.