


USER MANUAL

EN



IN THE BOX



Bell
(including a lanyard)



USB TYPE-C
Charging Cable



How to install a bell (optional)

1. Open the soft button , and connect a little bell to the hook.
2. Remember to close the button tightly to prevent the bell from falling off the hook .



QUICK START GUIDE

1. Turn on and select an interactive mode.




On/OFF *Press the button over 3 seconds

Modes Selection * Press the button once for one mode

Playing Mode
Mild (Only for moving. Moving 10S,stop 1S)
Simple (Move and Jump,moving 20S ,stop 5S.If the cat taps it,jump 5S)
Active (Only jumping , Jump 5S then stop 10S again)

2. How to activate your Smart Ball

After selecting the interactive mode,
It will be activated automatically after 2 seconds .



Remark:
*Before having fun with your cat , please check that your smart ball's surface in good condition.
*Supervision is required during the playtime to prevent your pet from swallowing .

3. BLE APP Connection

Scan the QR code to download and install the app .

This app is compatible with iOS 9.0 and Android 4.0 or above.
iOS system: please search "Smart Life " in the app store.

Android system : Please scan the QR code or search "Smart Life" on Google Play to download.



Register & log in App:

Turn on the Bluetooth function on mobile phone.

Press the button on smart ball for 6 seconds to active BLE signal.

APP Description :

- Direction Control:Use the app , can control the ball move forward or backward.
After 10 seconds it will auto turn back to the auto playing mode .
- Seeking mode: Select "Seek" function on app ,you will hear the "Di..." sound from ball ,help you lock out the ball location .
- Mode Selection : Three playing modes switched at will .
- Battery Percentage: Please notice the battery status, charging the ball in time.

Remark : Please keep your phone Bluetooth always on

STATUS OF LED INDICATOR



Blue: Mild mode

Blue&Red: Simple Mode


Red: Active Mode

Manually switch the playing modes, each mode can be played all the time, using mobile APP to control the pet's playing time.




HOW TO CHARGE

1. Low battery



Press and hold the button, if the LED indicator is flashing red or there is no response , please charge your smart ball.

2. Opening the soft button to charge



Charging (Flashing blue)

Full charged (Blue) *Status of LED when charging

*It takes about half hour to be fully charged .

*Plug the USB cable into a USB power socket

SPECIFICATION


Model : T1

Weight: 110g


Dimensions: 47mm*50mm

Battery : 3.7V ,230mah Li-ion


Operating Temperature : 15°C-40°C




How to replace the shell



1.Unscrew the old shell



2. Replace the new shell, the assemble direction as above photo



3. Tighten the new shell until hear the "Pop" sound.

Warranty

We offer 90 days warranty for smart ball against any quality-related defects. Warranty starts from the date you receive your item.Warranty claims for product defects expire 90 days after opening a warranty claim .

Warranty are voided for /if :

- Wrong item/component returned to us .
- Damage arising from importer use or maintenance (including, but not limited to :falls ,extreme temperatures,operating devices improperly)
- Damage arising from accident or external causes
- Damage arising from abnormal wear and tear
- Damage arising from unauthorized repair ,modification or customization
- Item used by other pets rather than the designated pets stated in product description (e.g. smart ball used by dog)
- Normal wear down of the outer shell, battery of smart ball .

Warranty are also voided for /if :

- Lost or stolen items
- Items that have expired their warranty period
- Free products
- Products that have been fully refunded
- Any consumable items/parts supplied with the warranty item
- Any accessories not being part or component of the warranty item
- Proof of purchase is not provided by buyer
- Items purchased from an unauthorized seller.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.