

# USER MANUAL

For more questions,  
please consult online  
customer service.

## Connection settings

### 1 WiFi connect (For Android device and Cast device)

Open Settings - Network & WiFi (picture 1) to enter the WiFi settings, page 1 (picture 2)

Choose the WiFi option and enter passwords to connect.




Click "Next" in software keyboard to connect WiFi after passwords entered.

If the pop-up window of "Problem with Authentication" appears, it means that the password is incorrect. If the pop-up window of "Saved", it may be that the router's WiFi settings are limited. It is recommended to check as follows:

Turn off the WiFi for seconds and turn on again to connect. Reboot the router and connect again, try to reduce the connected devices. Connect to the mobile phone hotspot to check if the projector WiFi work properly.

## Projection Distance Reference & Screen Adjustment

### 1 Projection distance reference



### 2 Sharpness adjustment



1. After the machine is placed horizontally, turn the focusing ring up and down to adjust the picture to be clear.

2. If the machine installed tilted, please set the keys to the correction to adjust. If unable to get the self-sharpening, move the machine

to check as follows:

1. Turn off the WiFi for seconds and turn on again to connect. Reboot the router and connect again, try to reduce the connected devices. Connect to the mobile phone hotspot to check if the projector WiFi work properly.

2. Warn: The machine filter and air outlet must not be blocked or too close to the wall. Clean the filter regularly every month to prevent clogging.

## Power-On/Off Operation

### 1 Power connection



### 2 Boot & Shutdown

- Press the power button to boot up projector
- Power on/off by the button on projector
- Aim the remote control to the projector

## Remote Control Button Function

### Remote Component and Functions




### Voice pairing method

1. Press and hold the left & right direction buttons at the same time for 3-5 seconds until the red light flashes.

2. Open Settings - Remote Control & Accessories - click the name of the Voice Assistant to connect (as shown in the picture).

## Projector Accessories

### AV port



### Ventilation holes



### lens

Notice: Do not look directly at the lens to prevent eye injury!

## Important Safety Notes

For the best viewing effect, please use the projector in dark room

1. Do not install this projector in the area which directly blown by the air conditioner, to prevent projector failed caused by water vapor condensation or excessive temperature.

2. Ensure that the environment is ventilated to prevent overheating caused by heats build-up.

3. Prevent foreign objects from falling into the machine. Never insert any metal objects into the machine! If foreign objects fall into the machine accidentally, please power off immediately and seek professional assistance.

4. Do not place any liquid on the machine to avoid leakage

5. Avoid violent vibrations when transporting. Please protect the lens from wear.

6. Do not touch the vents when using the projector to avoid

burns due to excessive temperature.

7. Do not look directly at the lens while the projector is running to prevent eye injury.

8. Please clean the filter regularly to prevent malfunction caused by clogging.

### Notice

Do not open the case of projector to prevent electric shock. Please seek professional assistance for maintenance matters.

### Notice

Do not touch! The inside of the projector contains unisolated voltage.


### Warn

Do not install the projector around flammable objects to prevent fire. Please use IEC-certified power adapter for charging.


### Notice

Please read this user manual carefully before use.





**Due to the continuous update of the design, the software interface may be slightly different from this picture, please refer to the actual product.**



#### Screen Cast for Android Phone (support Android 5.3 and above)

1

Press the "Switch" button on projector or the signal button of remote to choose the signal source.(As picture 1).

2

Only on Android interface: open Settings - Signal(picture 2).



#### Wireless Screen Mirroring for iPhone

1

Please ensure the ios device and projector connected to the same network.

2

Open the "CoolAirMirror"App in projector.

3

Open the Wireless Cast on Android phone to search available devices, click the 'Android\_XXXX' option to connect.

4

Click on the prompt box to accept the screen cast connection. If the screen is synchronized, means screen cast completed.

3

Open the Screen Mirroring from the control center on iPhone.

4

Search for available devices.

5


Connect to "ByteFly—XXXXXX" option to start mirroring screen.

#### Connection Settings (Introduction of different versions)

1

Projector-Multimedia version

Multimedia version projector can play content from HDMIinput or USBtransmission from laptop or set-top-



#### 2 Projector-Cast version

Cast version projector can both play HDMI input content and the content shared by mobile phone screen mirroring.

#### 3 Projector-Cast version

Smart projector available to preinstall variousapplications to play network video.

#### Filter Cleaning

##### 1 Filter Cleaning



Pull out the filter and clean the dust on it, then install it back.

#### Projector Common Troubleshooting

1

Remote control is insensitive or unresponsive

— Please check if the batteries installed properly.  
— Please replace with new batteries.  
— Please aim the remote control to the projector to operate.

2

Unable to boot up

— Please check if the power cord is connected properly, andif the power light is 'on'. Try to unplug and plug the powerif the projector still cannotboot up.

#### 3 Black screen or abnormal picture after booting for a while

— Please check if the vents are blocked.  
— Please check if the cooling fan is working properly. If abnormal,please return for repair.  
— Please try to reboot the projector.

#### 4 No network connection

— Please check if WiFi connected properly, and if the WiFi signal is good.  
— Please connect hotspot of smart phone to verify if routeris working properly.

#### 5 Blurry display

— Please check if the lens are clean.  
— Please use the focusing ring to adjust the sharpness.  
— Please check if the environment too bright.

#### Projector Common Troubleshooting

6

Screen freeze

— Please reboot the projector to test again. If the screen still freeze, please turn off for 10minutes and turn on again.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 10cm between the radiator and your body.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Warranty Card

1. This projector supports Three-Guarantees. Service Warranty for 1 year from the date of purchase (non-artificial damage).

2. Within warranty, we support warranty service for any failures caused by product technology.

3. The following situations are not covered by the warranty:  
— Accessories except the projector.  
— Products that have been disassembled and repaired without permission.  
— Damage caused by external force and other natural disasters.

4. When the product fails, please contact the dealer or supplier in time to arrange for repair with this warranty card.

5. This warranty liability is limited to product failure repairs within the warranty period.

#### Warranty Card

Client Name: \_\_\_\_\_

Client ID: \_\_\_\_\_

Purchase shop: \_\_\_\_\_

Customer Phone Number: \_\_\_\_\_

Return Address: \_\_\_\_\_

Fault description: \_\_\_\_\_

(For quick repair, please describe in detail): \_\_\_\_\_