



WHAT'S IN THE BOX?



Template Sticker for the wall

HD Mount set
HD Mount and
HD Magnet


Ambient Light



3 Fischer DuoPower plugs


universal plugs for
plasterboards, bricks,
concrete and blocks

1 USB-C type cable



REQUIRED TOOLS

(not included)



Power drill with
6 mm drill bit
(~1/4")



Hammer



Phillips-head
screwdriver or
screwdriver bit




Note: The included expansion
plugs are not intended for
wood. If you want to mount
Ambient Light on wooden or
fibreboard walls, please skip
steps 1 and 2, and use only
the screws.



Displate

AMBIENT LIGHT



USER GUIDE

Manufacturer:
GWD Concept Sp z o.o.
Al. Jerozolimskie 123a
02-017 Warsaw
Poland

AMBIENT
LIGHT
MODEL: AL0001

CE FC
MADE IN POLAND
displate.com/ambient-light



Do not throw it in
the trash, and please
treat it with care.



Lumino only works
indoors, since it's
neither waterproof nor
dustproof.



Not intended for
children under
12 years of age.




We don't recommend
using other mounting
methods.

Powered by **twinkl**

SET UP YOUR AMBIENT LIGHT

YOU'LL NEED TO USE THE TWINKLY™ APP TO GET THE MOST OUT OF YOUR AMBIENT LIGHT. IT'S SUPER EASY AND TAKES JUST A FEW MINUTES TO SET UP. HERE'S WHAT YOU NEED TO DO:




1 Download and install the Twinkly™ app from Google Play or Apple app store.




2 Create the account in the app or log-in. Displate accounts do not work in the app.



3 Press the power button once to turn on the Ambient Light. Press twice, if you ever need to turn it off.




4 Press the SYNC button briefly, until the green LED turns light blue.



5 If Ambient Light is not syncing automatically, choose the "Other devices powered by Twinkly" category. Default local Wi-Fi password: displate1111




6 Ambient Light works best when it's paired with the app over a WiFi network. Find more information about Twinkly app here: <https://help.twinkly.com/>




7 Now, you have full control over your Ambient Light! Customize the colors, map your Displates, create light animations behind the posters – go nuts!

2. WALL MOUNTING


READY? THE MOUNTING PROCESS IS JUST AS QUICK, EASY, AND HASSLE-FREE AS YOU'D EXPECT FROM A DISPLATE PRODUCT. HERE'S HOW YOU DO IT:





1 Place the Template Sticker on the wall and drill holes in the indicated places.



2 Insert the expansion plugs into the holes (push them in by tapping lightly with a hammer) and use the screws and bolts to attach the HD Mount to the wall.



3 Slide the Ambient Light inside the HD Mount. Next, slide the HD Magnet inside the Ambient Light. Hang your Displate and you're good to go!



DISPLATE COMPATIBILITY

AMBIENT LIGHT CAN BE A POWER SOURCE FOR LUMINO



M



L



XL



LUMINO

3. CHARGING AMBIENT LIGHT


AMBIENT LIGHT NEEDS SOME FRESH JUICE EVERY NOW AND THEN TO KEEP ITS GLOW ON. YOU'VE GOT THREE OPTIONS HOW TO DO IT.

NOTE:
Ambient Light works up to 30 hours on a single charge.


THE FIRST METHOD:




1 Turn off the Ambient Light in the Devices category in Twinkly Application.



2 Remove your Displate. Slide out the Ambient Light.



3 Extract the HD Magnet and put it back on the HD Mount. You can put your Displate back on the wall while Ambient Light is out charging.



4 Connect Ambient Light to a USB charger or a computer USB port. It takes about 8 hours to fully charge Ambient Light with a phone charger. Charging with a computer USB port takes around 40 hours.

THE SECOND METHOD:

Remove your Displate. Connect the charging cable and put the poster back. Keep charging your Ambient Light while it's still on the wall.

THE THIRD METHOD:

Power Ambient Light trough Lumino. Connect Ambient Light to the top USB-C port on Lumino. Connect the charging cable to the other USB-C port on Lumino, and plug it into a phone charger or any other USB charger.

The white LED above the POWER button starts flashing when your Ambient Light is running out of charge. After charging, the white LED gives off a steady light.