

Appendix II

Internal Photographs

Open View of EUT




Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




Internal View of EUT-4




Internal View of EUT-5



Internal View of EUT-6



Internal View of EUT-7




Internal View of EUT-8




Internal View of EUT-9




Internal View of EUT-10




Internal View of EUT-11




Internal View of EUT-12




Internal View of EUT-13




Internal View of EUT-14




Internal View of EUT-15




Internal View of EUT-16




Internal View of EUT-17




Internal View of EUT-18




Internal View of EUT-19




Internal View of EUT-20




Internal View of EUT-21




Internal View of EUT-22




Internal View of EUT-23




Internal View of EUT-24




Internal View of EUT-25




Internal View of EUT-26




Internal View of EUT-27



Internal View of EUT-28




Internal View of EUT-29




Internal View of EUT-30




Internal View of EUT-31




Internal View of EUT-32




Internal View of EUT-33



Internal View of EUT-34



RF Module Location



Antenna Location

