


PAPAGO![®]

N268

User Manual



Disclaimer

1. Please follow the set-up and usage instructions in the print material that came with this Dashboard Camera (dash cam) product.
2. You should not set/install this dash cam at a place that would obstruct or reduce a driver's view; make sure your use complies with pertinent vehicle codes of your state, province, territory or country.
3. You should post the required notices of recordation to occupants inside the vehicle, if voices or other information/signal pertaining to in-vehicle activities will be recorded.
4. You should not change the dash cam's setting or mode of operation when the vehicle is in motion.
5. The optional driving warning signals, including any visual or audible reminder signals, should not replace your decision-making and judgment that are needed for the proper operation of the vehicle.
6. You should not leave the dash cam in a visible spot when no one is inside the vehicle, to avoid attracting break-ins to steal the unit, or other property.
7. You should avoid extended exposure of the dash cam to direct sunlight or extreme temperatures (either high or low temperature) which tend to degrade or damage the unit and its normal functionality.
8. You should examine, check and/or verify the dash cam at least every six (6) months, including the associated memory cards, to ensure the video reception and recording are working properly. For each use, you should verify that the dash cam unit, the visible lights and the audible sounds are working normally. If there are signs of non-operation or mal-function, you should immediately seek to replace the product and check to see if the product is covered under any applicable warranty.
9. The dash cam unit may have additional functionality, such as transmission and recording of audio or GPS signal or other identification information. If you have privacy concerns about these functions, make sure you follow the instruction to disable these functions.
10. You should use the dash cam unit in the way it was intended. You should not use the dash cam unit in a way that would be illegal, physically damages the unit, or tends to cause danger to the safe operation of the vehicle and/or occupants.

Attention Please

【About Usage】

1. If your vehicle still provides power when the vehicle is off, unplug the device when you plan to have your vehicle parked for a long period of time to avoid draining your vehicle's battery.
2. To avoid file corruption, don't eject the Micro SD Card immediately after powering off.
3. It is recommended to use provided adapter.
4. To enable motion parking monitor function, the unit must receive constant power.

【About Micro SD Card】


1. Please use Micro SD card with the size / memory of at least 32GB, Class 10 (up to 128GB).
2. Format Micro SD card before using.

1. Product Introduction

1.1 Package Contents

Check the items in your package with the list below. If any of the items are damaged or missing, contact your retailer.

- Device
- Car Charger



2. Start and Go

2.1 Power On

Insert the car charger cable into the car's cigarette lighter, and the other end into the Type-c USB port on the device . Make sure to install the Micro SD Card into the Micro SD Card slot on device. After turning on, the system will start recording automatically.

2.2 Power Off


When the power supply is off, the device will automatically shut down.

2.3 Button

Press the button: Start emergency recording.

Hold the button for 2 seconds: release the button once you hear a beep sound, and the device will be turned off.

Hold the button for 5 seconds: release the button after you hear the first and the second beep sound, the device will restore to factory settings.




3. Using App

1. App Installation

- ① Download and install the PAPAGO Focus App on your mobile device by scanning the QR code below.



- ② Searching for PAPAGO Focus on Google Play/App Store.



2. Ensure that the device is turned on and your mobile phone is within 5 meters of the camera.
3. Connect the WiFi on your phone.
SSID: PPG_N268_xxxx
Password: 12345678
4. Launch the app and add the device.
5. You can browse videos/photos and configure settings with the app now.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

