

Thanks for your order, please read below instruction to set up your device.

1. Remove the lid, Fill aquarium to the top with water. Distilled water is recommended
2. Plug device into an electric power supply or use 3PCS AAA battery to power the lamp, press "ON/OFF" button, the motor will start working, lights will change color automatically. Turn on the switch 30 seconds before putting the jellyfish in the aquarium.
3. Add 2-3 drops of liquid dish washing detergent. Place the jellyfish in the tank upside down so that they sink to the bottom.
4. During the first 48 hours you will notice bubbles adhering to the jellyfish causing them to gather at the top of the tank and not "swim" as intended. This is normal, gently remove air bubbles with a spoon or fork. After 48-72 hours the bubbles will dissipate allowing the jellyfish to swim as intended.
5. The motor shuts off automatically after 4 hours of constant use.
- 6: Multiple light settings can be selected by pressing the "Light" multiple times to cycle through the following color selections:
 - A. red-green-blue B. red/green C. red/blue D. green/blue E. red/green/blue
 - F. Light show-unit will automatically cycle through all the 5 color settings creating a mini light show for your enjoyment.
7. There are two different water flow speed for users to select from our lava lamp setting, the water flow speed controls how fast the jellyfish move.
 1. Turn on the lamp, it is quick water flow, the jellyfish move fast
 2. Press on/off again, it is slow water flow, the jellyfish move slowly
 3. Press on/off the third time, turn off the lamp, jellyfish stop moving.
9. Bluetooth: Press key & Open the Bluetooth setting on your phone and search for: Colorlife, click it and connect it successfully. If the speaker has previously connected with Bluetooth device, it will connect until another Bluetooth device is used. Speaker will automatically connect to the last device connected once it is activated. Speaker can only pair with one device at a time.
11. Avoid knocking over the device: While the lid has a tight seal it is not 100% waterproof, knocking over the device will cause the device to leak and may cause damages to surrounding area. We suggest keeping the unit out of the reach of kids and or pets, additionally do not set on top of electronic devices.
12. Change the water whenever you notice some cloudiness. Don't immerse the base in water, water can cause corrosion, a chemical reaction, with metal and the circuit board.
13. Each product will be filled with water for 24 hours for a leak-proof test. After such test, there may be water stains left inside the water tank, if necessary, use wet wipes to clean off it.
14. This product contains moving parts, some noise and vibration is to be expected, but if the noise is too loud, please email us.
15. There may be some unexpected happen during transit, If the lamp you received is leaking water/not work/no jellyfish, please contact support@gloryshineled.com
16. Use only adapter supplied.

Frequently Asked Question

1.Question: Unsuccessful pairing for connection

Make sure the speaker is in Bluetooth mode

Make sure the speaker has not connected with another device

Restart/Search the Bluetooth on the phone or tablet. Reconnect the speaker

2.Question: No voice or Distortion of the sound

Check the volume of your phone or the speaker, and adjust the volume

3.Question: Music breaking play

Make sure to stay within the recommended range of the device

Check if there is any walls/obstacle between the speaker and your device

4.Question: Why there are so many “Colorlife” when I connect with Bluetooth

That is because you have connected to another of our products, for example, you may have purchased multiple speakers from us and used it, that means there will be multiple “Colorlife” listed in your Bluetooth history.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna nr transmitter.