
















NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-
Outer_Full-0.009-0.15-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-
Outer_Full-0.15-30-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-
Outer_Full-30-1000-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-
Outer_Full-1000-3000-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-
Outer_Full-3000-6000-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-
Outer_Full-6000-26000-Ant1-PASS

