

12cm

Brookstone

www.brookstone.com

Model number: SB08N-70818

Description: Wireless Shower Speaker

Power: DC 5V 500mA

Output: 8W

Battery model: 602030 3.7V 300mAh 1.11WH

FCC ID: 2N413-SB08N70818

Brookstone®

WIRELESS SHOWER SPEAKER



This BROOKSTONE® trademark, name and logo are owned by BROOKSTONE HOLDINGS LLC. ©2023. All rights reserved. Manufactured, marketed and distributed by SAMSONIC USA LLC, under license. MADE IN CHINA

Please contact customer@samsonic.com for any questions.

SB08N-70818

ONE (1) YEAR LIMITED WARRANTY

Samsonic USA LLC ("Samsonic") warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Samsonic will either: 1) repair the defect at no charge, using new or refurbished replacement parts; or 2) replace the product with a new product that is at least functionally equivalent to the original product; or 3) provide a credit in the amount of the purchase price paid for the original product towards the purchase of other Samsonic products. A replacement product or part, including a non-replaceable part included in accordance with instructions provided by Samsonic, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Samsonic's property. When a credit is given, the original product must be returned to Samsonic and becomes Samsonic's property.

Obtaining Service: To obtain warranty service, contact us via e-mail: [customer-service@samsonic.com](mailto:customer-service@samsonic.com) or please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, part availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Puerto Rico and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Samsonic that can be identified by the "Samsonic USA LLC" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Samsonic products. Manufacturers or suppliers other than Samsonic may provide their own warranties to the purchaser. Samsonic, in no way, is permitted by law, provide these products "as is". This warranty does not apply to: a) damage caused by failure to follow instructions relating to product use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Samsonic; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capacity. (f) items intended to be personally reduced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models, and refurbished items; h) any modifications to the product; or i) a product that is used commercially or for a commercial purpose.

SAMSONIC SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, OR ARISING OUT OF ANY BREACH OF THE WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, SAMSONIC DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND WARRANTIES AGAINST DEFECTION OR LATENT DEFECTS. IF SAMSONIC CANNOT LAUFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION OF THIS EXPRESS WARRANTY.

IMPORTANT SAFETY INSTRUCTIONS - READ BEFORE USE

All of the safety and operating instructions should be read, adhered to and followed before using. Save these instructions for future reference.

- WARNING**

  - Keep the device away from heat, direct sunlight, and sharp edges.
  - Keep the device away from naked flames.
  - Do not insert any metal objects into the device as it may cause a short circuit.
  - To avoid a static charge, do not use the device in extremely dry climates.
  - Do not attempt repair the unit yourself. Contact a specialist.
- BATTERY PRECAUTIONS**

  - Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
  - Do not leave the batteries where a child or pet could play with or swallow them.
  - If new batteries are swallowed, contact a physician immediately.
  - The batteries may explode if recharged.
  - Always use, and recharge if applicable, batteries under adult supervision.

CARE INSTRUCTIONS

- Clean the speaker with a dry cloth.

Product Overview:



- 2. Button Description**
- 1. **DC 5V**: To switch on or off the unit.
  - 2. **Play/Pause**: The music.
  - 3. **Phone**: To pick up or hang up a phone call.
  - 4. **Volume**: Short press for the next song. Long press for turning up the volume.
  - 5. **Power**: Short press for the previous song. Long press for turning down the volume.

Notes & Tips:

- 1. You can press Phone button twice quickly to redial the last phone call.
- 2. **Headset mode**

Symptoms	Cause	Solutions
Can not switch the speaker on	Battery empty	Charge the battery
Unable to pair the speaker	Speaker is already switched on, and it is not in pairing mode.	Refer to the section of "Pairing BT with a mobile phone or other device"

Some states **disallow** the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

**CAUTION:** THE PRODUCT MUST BE USED BY AN ADULT AND KEPT OUT OF REACH OF CHILDREN. THE PRODUCT SHOULD BE USED STRICTLY IN ACCORDANCE WITH THE DIRECTIONS PROVIDED HEREIN. AT NO TIME SHOULD THE PRODUCT BE MODIFIED OR ALTERED IN ANY WAY.

Supplier's Declaration of Conformity

AT CPE 8.2-2017 Compliance Information

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Supplier's Declaration of Conformity**

AT CPE 8.2-2017 Compliance Information

**Supplier:** Brookstone® SB08N-70818 WIRELESS SHOWER SPEAKER

**Responsible Party:** US, Contact Information

Brookstone, Inc.  
Plymouth, Minnesota 55446  
customer-service@samsonic.com  
Brookstone, Minnesota 55446  
FCC Compliance Statement  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
1) This device may not cause harmful interference, and  
2) This device must accept any interference received, including interference that may cause undesired operation.

HOW TO USE:

Accessories Included

- 1 x USB charging cable

Charging Integrated Battery

This Wireless speaker is powered by an integrated rechargeable Lithium battery. Charge the battery as follows:

- 1. Insert the charging cable into the DC 5V socket on the unit. Connect the USB plug into a PC or AC (DC) adapter. The LED indicator turns red when the battery is being charged.
- 2. When the battery is fully charged, the red LED indicator goes out.

Pairing Speaker to a Mobile Phone or other Device

- 1. Turn OFF the power of the speaker.
- 2. Press and hold the On/Off/Power button until the light-blue flashes, now the speaker is in pairing mode and discoverable to phone or other device.

- 3. Go to your phone or device settings and select Bluetooth settings and select BT-546. When done, the screen shows that the speaker is connected.
- 4. The Speaker will automatically connect to your phone or device next time when the speaker is switched on.

12cm

2023/09

